Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR

lv	OCD Artesia	

FORM APPROVED OMB NO. 1004-0137

BUREAU OF LAND MANAGEMENT	· · · · · · · · · · · · · · · · · · ·	Expires: Januar
BUNDAU OF LAND MANAGEMENT	5. Le	ase Serial No.
RY NOTICES AND REPORTS ON WELLS	l Ni	MLC028793A

COMPINE	OTIOEO AND INEL O	INTO OIL WELLS
Do not use this	form for proposals to	drill or to re-enter an
		PD) for such proposals.

6. If Indian, Allottee or Tribe Name

abanaonea won.		
SUBMIT IN TR	7. If Unit or CA/Agreement, Name and/or No. NMNM88525X	
Type of Well Oil Well	INJECTION	8. Well Name and No. BURCH KEELY UNIT 97
Name of Operator Contact: ABIGAIL MONTGOMERY COG OPERATING LLC E-Mail: Abbym@bcmandassociates.com		9. API Well No. 30-015-04209-00-S1
3a. Address 600 W ILLINOIS AVENUE MIDLAND, TX 79701	3b. Phone No. (include area code) Ph: 432-580-7161	10. Field and Pool or Exploratory Area GRAYBURG
4. Location of Well (Footage, Sec., T., R	R., M., or Survey Description)	11. County or Parish, State
Sec 19 T17S R30E NESE 2615F	FSL 1295FEL	EDDY COUNTY, NM

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)	☐ Water Shut-Off
_	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation	Well Integrity
☐ Subsequent Report	Casing Repair	■ New Construction	☐ Recomplete	□ Other
☐ Final Abandonment Notice	☐ Change Plans	☑ Plug and Abandon	□ Temporarily Abandon	
	☐ Convert to Injection	□ Plug Back	☐ Water Disposal	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.

1. Spot 25 sx cmt @ 3026-2896. WOC & Tag. Circulate hole w/ MLF. Pressure test csg.
2. Spot 15 sx cmt @ 1000-800. WOC & Tag
3. Spot 45 sx cmt @ 556- Surface.
4. Cut off well head, verify cmt to surface, weld on Below Ground Dry Hole Marker.

ATTACHED

RECLAMATION PROCEDURE

ATTACHED

CHME

Accepted for record - NMOCD

SALE ATTACHED FOR CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct. Electronic Submission #403661 verified by the BLM Well Information System For COG OPERATING LLC, sent to the Carlsbad Committed to AFMSS for processing by PRISCILLA PEREZ on 02/21/2018 (18PP1158SE)					
Name (Printed/Typed)	ABIGAIL MONTGOMERY	Title	AGENT		
Signature	(Electronic Submission)	Date	02/07/2018		
THIS SPACE FOR FEDERAL OR STATE OFFICE USE					
Approved By	mer Ce Ones	Title	Super AET	3.248 Date	
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office			

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

COG Operating, LLC

Lease & Well # **Burch Keely Unit 97** WIW 3001504209 Sec 19 T 17S R 30E, 2615 FSL & 1295 FEL Spud date 9/251949 EDDY CO., NM Completion Date 11 /2/1998 (recompletion) Elevation - 3630 Calculated TOC @ 214' FS. 11" hole Perf'd squeeze hole @ 500'

B/Salf 906

Porf'd squeeze hole @ 920' 8 5/8" set @ 506', 75 sx cmt. 3. Spot 45 sx cmt @ 556'-Surface. Perf'd squeeze hole @ 930" 2. Spot 15 sx cmt @ 1000-800'. WOC & Tag. Casing cementing calculations 8 5/8" 24# 11" Hole Cement volume. =75 X 1.32 CF/SK = 99 cu. Ft. slurry 99 - 25% slurry loss for shoe joint & hole loss = 74.25 5CF GB 2347

SA 2763

Lov. Sa J 2868

Calculated TOC @ 2,125' fs 74.25 CF X ann. Vol. of 3,9337 FT/CF = 292" 506 - 292' = 214' estimated (calculated) top of cement. 7" 20# 8 1/4" hole 100 sx Cement volume = 100 X 1.18 CF/SK = 118 cu.ft. slurry. 118 - 25% slurry loss for shoe joint & hole loss = 88 8.5 cf 88.5 CF X ann. Vol. of 9.6182 FT/CF =851' 2976 - 851 = 2125' estimated (calculated) top of cement. 2510 2516 500 gal HCL, frac w/20,000 gal GW, 20,000 #sd Squeezed 2536 - 2584' frac w/30,000 gal GW, 30,000 #sd Squeezed 2745 - 2751 500 gal HCL, frac w/20,000 gal GW, 20,000 #sd Squeezed 2871 - 2877 500 gal HCL, frac w/20,000 gal GW, 20,000 # sd Packer fluid Squeezed 1. Spot 25 sx cmt @ 3026-2896'. WOC & Tag. Circ hole 2 3/8" Salta lined tbg. SN. 4 1/2" R-4 PC pkr @ 2925' w/ MLF. Pressure test csg. Cmt w/400 sx Interfill H, 100 sx PP, circulated 20 sx to surface Shut in 7", pumped 2 bbl FW, squeezed to 1,000 psi. 4 1/2 " 11.6# J-55 LTC csg @ 2946' 10/28/1998 7" 20# csg @ 2976', 100 sx cmt. 9" hole TD OH @ 03240 OH completion 2976-3240', IP 4 1/2 BOD 11/28/1949

TD 3,240'

COG Operating, LLC

Lease & Well # **Burch Keely Unit 97** 3001504209 Sec 19 T 17S R 30E, 2615 FSL & 1295 FEL Spud date 9/251949 EDDY CO., NM Completion Date 11 /2/1998 (recompletion) Elevation - 3630 Calculated TOC @ 214' FS. 11" hole 8 5/8" set @ 506', 75 sx cmt. Perf'd squeeze hole @ 500' Casing cementing calculations 8 5/8" 24# 11" Hole Perf'd squeeze hole @ 930" Cement volume, =75 X 1.32 CF/SK = 99 cu. Ft. slurry 99 - 25% slurry loss for shoe joint & hole loss = 74.25 5CF 74.25 CF X ann. Vol. of 3,9337 FT/CF = 292" 506 - 292' = 214' estimated (calculated) top of cement. 7" 20# 8 1/4" hole 100 sx Cement volume = 100 X 1.18 CF/SK = 118 cu.ft. slurry. 118 - 25% slurry loss for shoe joint & hole loss = 88 8.5 cf 88.5 CF X ann. Vol. of 9.6182 FT/CF =851* 2976 - 851 = 2125' estimated (calculated) top of cement. Calculated TOC @ 2,125' fs 2510 2516 500 gal HCL, frac w/20,000 gal GW, 20,000 #sd Squeezed 2536 2584' frac w/30.000 gal GW, 30,000 #sd Squeezed 2745 - 2751 500 gal HCL. frac w/20,000 gal GW, 20,000 #sd Squeezed 2871 2877 500 gal HCL, frac w/20,000 gal GW, 20,000 # sd Packer fluid Squeezed 2 3/8" Salta lined tbg, SN. Cmt w/400 sx Interfill H, 100 sx PP, circulated 20 sx to surface 4 1/2" R-4 PC pkr @ 2925" Shut in 7", pumped 2 bbl FW, squeezed to 1,000 psi. 4 1/2 " 11.6# J-55 LTC csg @ 2946' 10/28/1998 7" 20# csg @ 2976', 100 sx cmt. 9" hole TD OH @ 03240' OH completion 2976-3240', IP 4 1/2 BOD 11/28/1949 TD 3,240°.

32. 420034 -{04.3069733

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval (LPC Habitat)

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brine water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Below Ground Level Cap (Lesser Prairie-Chicken Habitat): All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off. Upon the plugging and subsequent abandonment of wells that are located in lesser prairie-chicken habitat, the casings shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be covered with a metal plate at least ¼ inch thick and welded in place. A weep hole shall be left in the plate and/or casing.

NMOCD also requires the operator to notify NMOCD when this type of dry hole marker is used. This can be done on the subsequent report of abandonment which is submitted to the BLM after the well is plugged. State that a below ground cap was installed as required in the COA's from the BLM.

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date well was plugged.</u>
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.

<u>Timing Limitation Stipulation/ Condition of Approval for Lesser Prairie-Chicken:</u>
From March 1st through June 15th annually, abandonment activities will be allowed except between the hours from 3:00 am and 9:00 am. Normal vehicle use on existing roads will not be restricted



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of
 Operations must include adequate measures for stabilization and reclamation of disturbed lands.
 Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD
 process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you

have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Petroleum Engineering Tech 575-234-5909, 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Henryetta Price Environmental Protection Specialist 575-234-5951

Shelly Tucker Environmental Protection Specialist 575-234-5979

Trishia Bad Bear, Hobbs Field Station Natural Resource Specialist 575-393-3612