

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.
30-005-61166

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

Caudill RZ

7. Well No.

1

8. Pool name or Wildcat
Pecos Slope Abo

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 S. 4th Street Artesia, NM 88210

4. Well Location

Unit Letter D : 660 feet from the North line and 660 feet from the West line

Section 8 Township 6S Range 26E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3707'GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Yates Petroleum Corporation proposes to plug and abandon this well as follows:

1. Notify the NMOCD at least 24 hrs before starting the work. Load the tubing and the casing with 2% KCL water then ND the wellhead and NU the BOP.
2. Set a 4-1/2" CIBP at 3730'. Circulate hole with 10.0 ppg mud with 25#/bbl of gel in the mud. Spot 25 sx cement on top of the CIBP. *Leave 100' of cement 1550'-1650'.*
3. Shoot 4 holes at 1650', squeeze 50 sx cement behind the casing to cover the Glorieta. Shoot 4 holes at 978', squeeze 50 sx cement behind the casing to cover the base of the 8-5/8" casing. Shoot 4 holes at 100' then screw in a casing swage and squeeze 50 sx cement behind the casing to the surface. Spot 5 sx cement at the surface to fill up the casing if necessary. *-WOC 24 HRS - TMS*
4. ND the BOP and remove the wellhead and install a dry-hole marker and clean up the location. ** Place 100' of cement from 428'-528' inside & outside of Csr.*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Compliance Supervisor DATE June 30, 2003

Type or print name Tina Huerta

Telephone No. 505-748-1471

(This space for State use)

APPROVED BY [Signature] TITLE Libby Sep 11 DATE 7-1-03

Conditions of approval, if any: