Submit 1 Copy To Appropriate District State of New Mexico	Form C-103						
Office District I - (575) 393-6161 Energy, Minerals and Natural Resources	Revised July 18, 2013						
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.						
District II - (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CONSERVATION DIVISION	30-015-21313						
District III - (505) 334-6178 1220 South St. Francis Dr.	5. Indicate Type of Lease STATE ☑ FEE □						
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460 Santa Fe, NM 87505	6. State Oil & Gas Lease No.						
1220 S. St. Francis Dr., Santa Fe, NM	B-2071						
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	7. Lease Name or Unit Agreement Name NG Phillips State 8. Well Number 12						
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	o. Well Nulliber 12						
2. Name of Operator	9. OGRID Number						
COG Operating, LLC	229137						
3. Address of Operator	10. Pool name or Wildcat						
600 W. Illinois Ave, Midland, TX 79701	E. Empire- Yates- SR						
4. Well Location							
Unit Letter 1650 feet from the N line and	1650 feet from the W line						
Section 27 Township 17S Range 28E	NMPM County Eddy						
11. Elevation (Show whether DR, RKB, RT, GR, etc.	2)						
3654' GR							
12 Charle Assuranciata Dan to Justineta Natura (Nation	December Other Determine						
12. Check Appropriate Box to Indicate Nature of Notice	, Report of Other Data						
NOTICE OF INTENTION TO: SUI	BSEQUENT REPORT OF:						
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WO							
	RILLING OPNS. P AND A						
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME	NT JOB						
DOWNHOLE COMMINGLE							
CLOSED-LOOP SYSTEM	П						
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date							
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of							
proposed completion or recompletion.							
1. Set 4 ½" CIBP @ 760'. Circulate hole w/ MLF. Pressure test csg. Spot 25 sx	cmt @ 760-500' WOC & Tag						
2. Spot 25 sx cmt @ 350'-Surface.	cmt w 700-300 . W Oc de Tag.						
3. Cut off well head, verify cmt to surface, weld on Dry Hole Marker.							
	RECEIVED						
Notify OCD 24 hrs . Pri	or 10						
any work done.	OCT 0 9 2018						
	001.49.9.5010						
	DISTRICT II-ARTESIA O.C.D.						
Could Date:							
Spud Date: Rig Release Date:							
* See Attach of COA's Most be	Plusel by 10-10-19						
I hereby certify that the information above is true and complete to the best of my knowled							
Thereby certify that the information above is true and complete to the best of my knowled	ge and belief. /						
10							
Type or print name Abigail Montgomery E-mail address: E-mail address:	DATE 10/41 2018						
abbym@bcmanda	ssociates.com						
Type or print name Abiqui Montgomery E-mail address:	PHONE: <u>432-580-716</u>						
For State Use Only							
APPROVED BY: AFF MITTLE STATE MITTLE MI	DATE 10-10-18						
Conditions of Approval (if any):	55/0/1						

Field & Pool ____ Easte Empire Yates-7 Rivers

RAN 7" 20# CSG, SET @ 513' Pulled 7" casing and set 4-1/2" casing	Csg: Set @ Cement w/ circ.	Well ID Info: API No: 30-015-21313 Spud Date: 8/15/1974
	Tubing Detail 2-3/8" Tubing EOT @ 786' Yates 7 Rivers: 771' - 777' Gelled water fra 44,500 # sand	Rod Detail 1 1/4" X 22' P/R W/ 1 1/2" X 5' LNR 30 - 3/4" RODS 2' X 3/4" SUB 6' X 3/4" SUB 2" X 1 1/2" X 10' RWTC #Y-8315 13 Holes c
PBTD 809 [.] TD 830 [.]	Csg: Depth: Cement w/ circ.	4-1/2" 10.5# 828' 225 sx Cemented to with 75' Cemented on surface with 6 yards ready-mix

Field & Pool Easte Empire Yates-7 Rivers

	Well ID info:			II ID Info:	
				API No:	30-015-21313
				Spud Date	8/15/1974
	Csg:		<u>•</u>		
	Set@		-		
	Ceme	nt w/	-		
RAN 7" 20# CSG, SET @ 513'	circ.		•		
Pulled 7" casing and set 4-1/2" casing					
	2. Sp	ot 25 sx	cmt @ 350'-Surface.		
	** **				
			IBP @ 760'. Circulate I		Pressure test
	csg. S	Spot 25 s	sx cmt @ 760-500'. WO	C & Tag	
	3				
	¥ ≜				
	_ Yates	7 Rivers			
	771' -		13 Holes		
		l water fr			
	= 44,50	0 # sand			
	37 33				
	Š				
	8 8				
PBTD 809'	Csg:		4-1/2" 10.5#		
TD 830'	Depti		828'		
	 Ceme	nt w/	225 sx		
	circ.		Cemented to with 75'		
			Cemented on surface	with	
			6 yards ready-mix		

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)