

Form 3160-5
(November 1983)
(Formerly 9-331)

**UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT**

SUBMIT IN TRIPLICATE *
(Other Instructions on
reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.
LC-029419-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL ☐ GAS ☐ OTHER ☐
WELL WELL WIW - P & A

7. UNIT AGREEMENT NAME
Skelly Unit

2. NAME OF OPERATOR
The Wiser Oil Company

8. WELL NO.
42

3. ADDRESS OF OPERATOR
P.O. Box 2568 Hobbs, New Mexico 88240 (505) 392-9797

9. API WELL NO.
30-015-05356

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FNL & 1880' FEL
Unit B

10. FIELD AND POOL, OR WILDCAT
Grayburg Jackson 7-Rivers-QN-GB-SA

11. SEC. T. R. M. OR BLK. AND
SURVEY OR AREA
Sec. 22-T17S-R31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3875' DF

12. COUNTY OR PARISH
Eddy County

13. STATE
NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF ☐ FULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☒
REPAIR WELL ☐ CHANGE PLANS ☐
(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐
(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser Oil respectfully request approval to plug and abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 616'. Production Casing: 4-1/2" set @ 3764' 11.60#

Perfs: 3188'-3606' 2283'-2400' CIBP @ 2100' & 3106' w/40 cement on plug.

1. Spot 50' plug on CIBP @ 2100'.
2. Perforate csg. @ 1700'. Place 100' of cmt. 51600'-1700' inside & outside of 4-1/2" csg. Tag cmt.
3. 9# mud.
4. Perforate casing @ 670'. Circulate cement to surface. Leave a 100' plug @ 570'-670'.
5. Tag cement.
6. Spot 60' cement plug to surface.
7. Install dry hole marker.
8. Clean location.

18. I hereby certify that the foregoing is true and correct.

SIGNED Mike Jones TITLE Superintendent DATE November 7, 2002

Mike Jones

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instruction On Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.