Submit 3 Copies to Appropriate

## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

District Office OIL CONSERVATION DIVISION DISTRICT I WELL API NO. O. Box 1980, Hobbs NM 88240 2040 South Pacheco 30-015-01483 DISTRICT II 811 South First, Artesia, NM 88210 Santa Fe. New Mexico 87505 5. Indicate Type of Lease STATE 🛛 FEE DISTRICT III 6. State Oil & Gas Lease No. 1000 Rio Brazos Rd, Aztec, NM 87410 B-3149 A Company of the Comp SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS). 1. Type Of Well: OIL GAS Ø Red Lake Sand Unit OTHER WEI RECEIVED 2. Name of Operator 8. Well No. Mack Energy Corporation 27 JAN 2 6 7004 3. Address of Operator 9. Pool name or Wildcat P.O. Box 960, Artesia, NM 88211-0960 Red Lake; Queen-Grayburg-SA OCD-ARTESIA 4. Well Location South 1650 \_ Feet From The Feet From The Township Range NMPM 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT PULL OR ALTER CASING CASING TEST AND CEMENT JOB OTHER: OTHER 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Mack Energy Corporation proposes to plug and abandon well as follows: 1. Notify OCD 24 hours prior to starting plugging operations. 2. Set 100' cement plug from 1705-1605'. WOC and tag. 3. Circulate hole with mud gel. 4. Perforate @ 525' squeeze 100' cement 50' above and below 8 5/8 casing. WOC and tag. 5. Perforate @ 250' squeeze 100' cement back to 150'. - Both Strips 6. Perforate @ 60' circulate cement to surface. - Both Strings - WOC-14 HRS Tag 7. Install dry hole marker. 1/26/2004 Production Clerk DATE -TYPE OR PRINT NAME Jerry W. Sherrell TELEPHONE NO.

CONDITIONS OF APPROVAL, IF ANY

(This space for State Use)

## MACK ENERGY CORPORATION RED LAKE SAND UNIT #27 Sec 20 T17S R28E 2310FSL 1650FEL

| '8 5/8"-28# | 8 5/8"-28# Set @ 475' w/50sks | 7" 20# @ 1645' C/w 50sks | OPEN HOLE 1645'-1960'

- 1. Notify OCD 24 hrs. prior to any work done.
- 2.Set 100' cmt plug 1705-1605' and tag.
- 3.Circ hole with mud gel.
- 4.Perf @ 525' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
- 5. Perf @ 250' squeeze 100' cmt plug back to 150'
- 6. Perf @ 60' circ cmt to surface
- 7. Install Dry Hole Marker