

Federal "Q" 1 30-015-04068
CBS Operating Corp
October 2, 2007
Plug and Abandonment Procedure
Conditions of Approval

1. Ok
2. Ok
3. Casing to be pressured to 500 psi for 30 minutes to check casing integrity. TOH with packer.
4. CIBP must be knocked out to enable placing plug at bottom of hole and placing plug across 5-1/2" shoe. Plugs to be a minimum of 25 sacks and 130' in length. One 392' plug can be set from bottom of hole to 50' above shoe. Plug at shoe to be tagged at 2740' or shallower.
 - a. Plug required at base of Salt. Perforate casing at 1400' and squeeze cement. Plug to be tagged at 1300' or shallower.
5. Casing to be free pointed and removed. If free point is shallower than 500', contact BLM to discuss options.
6. With casing removed, set plug from 570-450'. This plug will cover top of Salt and 8-5/8" casing shoe. Tag plug.
7. Perforate 8-5/8" casing at 60' or deeper and set surface plug – minimum 60'.
8. Ok
9. Ok

WWI 100207