Submit 3 Copies To Appropriate District Office State of New Mexico	Form C-103
<u>District I</u> Energy, Minerals and Natural Resources 1625 N. French Dr., Hobbs, NM 88240	June 19, 2008 WELL API NO. 30-005-60427
District II 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	5. Indicate Type of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410 1220 South St. Francis Dr.	STATE FEE
District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO'NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	White Plains
1 Type of Well Oil Well X Gas Well Cher	8. Well Number 1
2. Name of Operator Ponderosa Petroleum Corporation	9. OGRID Number 248481
Ponderosa Petroleum Corporation 3. Address of Operator	10. Pool name or Wildcat
P. O. Box 132, Roswell, NM 88202	Chisum, San Andres, East
4. Well Location Unit Letter C: 330 feet from the North line and 2310 feet from the West line	
Section 21 Township 11S Range 28E	NMPMChaves County NM
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☑ REMEDIAL WORK ☐ ALTERING CASING ☐	
TEMPORARILY ABANDON	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB DOWNHOLE COMMINGLE	
OTHER: OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion	
or recompletion.	
We propose to Plug & Abandon the subject well as follows: NCBY OCD 24 hrs. prk	
(Note: On 1/11/07, CIPB was set at 2020'.) lo any work done.	
1)Spot 35 feet of cement at top of CIBP. 2)Load hole with mud.	
3) Shoot off casing at TOC, approx. 1500 ft., and reco	over casing.
4) Spot cement plug across casing stub, 50' in and 50' out(25 SX) & tag.	
(Note: This plug will also serve as the required plug at the top of the San	
Andres formation, top of SA at 1510 ft.) 5) Spot 35' (25 sx) plug at top of Queen formation at	970 foot
6) Spot shoe plug across shoe of surface pipe at 260 f	
50 sx and tag.	·
7)10 sx at surface with dry hole marker. 60 mr - C	<u> </u>
Spud Date: N/A Rig Release Date: N/A	
STEEL TANK WILL BE USED INSTEAD OF A PIT.	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
\mathcal{I}_{1}	
SIGNATURE TITLE President	DATE 8/14/08.
Type or print name Fred F. Pool, III E-mail address: Spool@cableone.net PHONE: 575 623-4667	
For State Use Only	
APPROVED BY: My Hanking TITLE Compline JATE 8/19/08	
Conditions of Approval (if any): Approval Granted providing, work	
is complete by 12/1/08	