

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.I.	
LAND OFFICE	
OPERATION	

OIL CONSERVATION DIVISION
P. O. BOX 20811
SANTA FE, NEW MEXICO 87501

RECEIVED BY
AUG 29 1984
O. C. D.
ARTESIA, OFFICE

FORM 12-103
Revised 12-1-77

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER ☒ Salt Water Disposal Well	10. Indicate Type of Lease State ☒ Free ☐
2. Name of Operator AMOCO PRODUCTION COMPANY	11. State Oil & Gas Lease No. B-8385-2
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	12. Unit Agreement Name State CF SWD
4. Location of Well UNIT LETTER <u>I</u> 1980 FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>13</u> TOWNSHIP <u>11-S</u> RANGE <u>27-E</u> N.M.P.M.	13. Field and Pool, or Wildcat San Andres Yeso
15. Elevation (show whether DF, RT, GR, etc.) 3757.1 GR	14. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to permanently plug and abandon the subject well as follows:

MISU, drop sinker bar and determine TCMT. RIH with 1-9/16" thru tubing gun and perforate tubing at 2000' ($\pm 190'$ above 8-5/8" shoe). Pressure up on backside to 500 psi and establish injection rate down tubing. If suitable rate and pressures are not obtained pump 250 gals of 15% HCL down tubing. Pump ± 400 sx class C with additives. Flush cement below cement top determined above. Perforate tubing above cement top and establish circulation back to surface. Pump 275 sx of class C cement down tubing and circulate out the annulus at surface. Erect PXA marker.

0+5-NMOCD,A 1-J. R. Barnett, HOU 21.156 1-F. J. Nash, HOU Rm. 4.206 1-GCC

Notify NMOGCC in sufficient time to witness

Plugging

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

VIEWED <u>Jerry C. Clark</u>	TITLE <u>Assist. Admin. Analyst</u>	DATE <u>8-28-84</u>
APPROVED BY <u>M. Williams</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>SEP - 4 1984</u>