

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	/
FILE	/ -
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO ODD DEEPER RESERVOIR  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSAL)

RECEIVED

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry Hole</b>	7. Unit Agreement Name
2. Name of Operator <b>Cities Service Oil Company</b>	8. Farm or Lease Name <b>O'Brien "A"</b>
3. Address of Operator <b>P. O. Box 69 - Hobbs, New Mexico 88240</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1780</b> FEET FROM THE <b>West</b> LINE, SECTION <b>3</b> TOWNSHIP <b>8S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Wildcat</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4002 DF</b>	12. County <b>Chaves</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well in the following manner:

1. Load hole w/mud laden fluid.
2. Set 25 sack cement plug across perfs. 2629-2929.
3. Cut 4 1/2' csg. at approx. 1775 and pull.
4. Set 25 sack cement plug @ cut point of 4 1/2' csg., @ approx. 1710-1835, half in and half out of stub.
5. Set 25 sack cement plug on top of Queen @ approx. 1269-1350.
6. Set 25 sack cement plug half in and half out of 8 5/8" csg. @ approx. 205-280.
7. Set 10 sack cement surface plug w/4' marker extending 4' above ground to designate a P & A location.
8. Clean location of all equipment and debris, fill pits and cellar.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. A. Gressett TITLE District Clerk DATE 9-30-66

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE 1966

CONDITIONS OF APPROVAL, IF ANY: