

NO. OF COPIES RECEIVED	✓
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

RECEIVED

JUL 1 1968

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- ARTESIA, OFFICE		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Cities Service Oil Company ✓		5. State Oil & Gas Lease No.
3. Address of Operator P. O. Box 69 Hobbs, New Mexico 88240		7. Unit Agreement Name
4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 35 TOWNSHIP 8s RANGE 28E NMPM.		8. Farm or Lease Name O'Brien "G"
15. Elevation (Show whether DF, RT, GR, etc.) 3940 DF		9. Well No. 1
		10. Field and Pool, or Wildcat Twin Lakes San Andres
		12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We proposed to P & A this well in the following manner:

1. Load hole with mud laden fluid.
2. Set 30 sack cement plug across perfs. from PBD 2640' to approx. 2280'.
3. Cut off 4½" casing at approx. 1900' and set 30 sack plug ½ in and ½ out of 4½" csg.
4. Set 30 sack cement plug across Queen Sand @ 1405.
5. Set 30 sack cement plug ½ in and ½ out of 8 5/8" casing @ 414'.
6. Set 10 sack cement surface plug with 4" well marker extending 4' above ground level to designate a P & A location.
7. Clean location of all equipment and debris, fill pits and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>C. D. ROBERTS</u>	TITLE <u>District Clerk</u>	DATE <u>June 27, 1968</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS BOARD (C)</u>	DATE <u>JUL 1 1968</u>
CONDITIONS OF APPROVAL, IF ANY:		