

RECEIVED

OCT 5 1972

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION
B. E. C.
ARTESIA OFFICE

NO. OF COPIES RECEIVED	1
DISTRIBUTION	
SANTA FE	
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. 5217	
7. Unit Agreement Name	
8. Farm or Lease Name Pecos State	
9. Well No. 1	
10. Field and Pool, or Wildcat Wildcat	
12. County Chaves	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole
2. Name of Operator AZTEC OIL & GAS COMPANY
3. Address of Operator P. O. Box 837, Hobbs, New Mexico 88240
4. Location of Well UNIT ENTER J 1980 FEET FROM THE South LINE AND 1980 FEET FROM East 36 LINE, SECTION 11S RANGE 25E TOWNSHIP 11S RANGE 25E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3448' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug & abandon this well in the following manner:

1. Set a 100' (30 sxs cement) plug over casing perforations at 5574-5674'.
2. Cut off 4 1/2", 10.5# casing at 4774'. Mix mud and circulate to balance fluid behind casing.
3. Set additional cement plugs as follows:
 - A 100' (30 sxs cement) plug at 4720-4820'. (Wolfcamp)
 - A 100' (30 sxs cement) plug at 3200-3300'. (Tubb)
 - A 100' (30 sxs cement) Plug at 1820-1920'. (Glorieta)
 - A 100' (30 sxs cement) plug at 1200-1300'. (In and out 8-5/8" casing)
 - A 80' (25 sxs cement) plug at surface.
4. Set well marker, level and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **original signed by LESTER L DUKE** TITLE **District Superintendent** DATE **9/22/72**

APPROVED BY **W. A. Grissett** TITLE **OIL AND GAS INSPECTOR** DATE **OCT 5 1972**
CONDITIONS OF APPROVAL, IF ANY: