

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Oil Cons. N.M. Div-Dist. 2

1301 W. Grand Avenue  
Artesia, NM 88210

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993  
Designation and Serial No.  
NM-11795

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Jack J. Grynberg

3. Address and Telephone No.

Tel: (303) 850-7490

5299 DTC Blvd. Suite 500, Greenwood Village, Colorado 80111

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FSL & 660 FEL  
Section 12, T6S, R24E

6. If Indian, Allottee or Tribe Name

NA

7. If Unit or CA, Agreement Designation

NA

8. Well Name and No.

Hobbs Canyon Fed#1

9. API Well No.

30-005-61367

10. Field and Pool, or Exploratory Area

Abo

11. County or Parish, State

Chaves, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well will be plugged as follows:

1. Set CIBP @ 3525 and cap with 35' of cement.
2. Circ hole with salt gel mixed with 25#/bbl brine water.
3. Equalize 100' cement plug inside 4½ casing from 1390 to 1290.
4. Perforate 4½ casing at 970'. Equalize 75 sk plug inside and outside 4½ casing. Tag plug.
5. Cut off casing strings 2' below ground level.
6. Lay 10 sk cement plug inside 4½ casing at surface.
7. Install dry hole marker 4' above ground level.
8. Cut off anchors and flowline 1' below ground level.
9. Clean and level location.

10 3/4 @ 920  
4½ @ 4107  
Perf. 3587-3840  
PBTO 4061  
TOC 920'  
Glorietta Top 1340'

Accepted for record - NMOCD

14. I hereby certify that the foregoing is true and correct

Signed K. APPROVED Title Engineer Date 3/7/2002

(This space for Federal or State office use)

(ORIG. SGD.) DAVID R. GLASS  
Approved by MAR 14 2002

Title \_\_\_\_\_ Date \_\_\_\_\_

SEE ATTACHED FOR

CONDITIONS OF APPROVAL

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side