

UNITED STATES OF AMERICA
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
NM Oil Cons. Commission
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
Grynberg Petroleum Company

3. Address and Telephone No.
5000 S. Quebec Street, Suite 500, Denver, CO 80237 (303)850-7490

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1980 FSL, 660 FWL, Sec 12, T6S-R24E

5. Lease Designation and Serial No.

USA-NM-11795

6. If Indian, Allottee or Tribe Name

NA

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Hobbs Canyon Fed #3

9. API Well No.

30-005-61455

10. Field and Pool, or Exploratory Area

Pecos Slope Abo

11. County or Parish, State

Chaves, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to P&A well as follows:

1. Set CIBP @ approx. 3450'.
2. Dump 35' cement on top with bailer.
3. Lay cement plug in 4½ casing from 1550 to 1450. (Bond log cement top is 1442'.)
4. Cut 4½ casing at ± 1400 and recover. Lay cement plug from 960 to 860' (10 3/4 shoe at 908'). WOC and feel for plug.
5. Lay surface plug in 10 3/4 casing 0 to 50'.
6. Cut off 10 3/4 casing below ground and install dry hole marker.
7. Contour and re-seed location.

Wellbore sketch attached.

14. I hereby certify that the foregoing is true and correct

Signed [Signature] Title Engineer

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title

Date 9/27/95

Date

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side