

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

RECEIVED

JUN 13 '90

Form C-103  
Revised 10-1-78

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BAYS TO A DIFFERENT AREA. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		3a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Slash Four Enterprises, Inc.		3. State Oil & Gas Lease No.
3. Address of Operator P.O. Box 1433, Roswell, N.M. 88201		7. Unit Agreement Name
4. Location of Well UNIT LETTER G, 1650 FEET FROM THE north LINE AND 2310 FEET FROM THE east LINE, SECTION 27 TOWNSHIP 10S RANGE 27E NMPM.		8. Farm or Lease Name Plainstec
15. Elevation (Show whether DF, RT, CR, etc.) 3822 gr		9. Well No. 2
		10. Field and Pool, or Wildcat Und. Diablo, SA
		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We Propose to plug this well as follows:

- Set CIBP above perforations, (2000') and dump two bailers of cement on top of plug.
- Cut and pull all free 4 1/2" casing, est. 1596'.
- Pump the following plugs:  
35 sx 50' inside of 4 1/2" stub. + Tag  
35 sx @ 990'-890' to cover top of queen @ 940'  
35 sx @ 458'-358' to cover 8 5/8' stub, we will tag this plug  
10 sx @ 30' to surface with dry hole marker.

Location will be cleared and leveled to NMOCD Rules and Regulations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE President DATE 6/12/90

APPROVED BY [Signature] TITLE Dist Seal DATE 6/20/90

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness  
Plugging