

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501 7 1981

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

O. C. D.  
ARTESIA OFFICE

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
B-11540

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL  GAS WELL  OTHER

1. Name of Operator  
W. E. Jeffers ✓

2. Address of Operator  
P. O. Box 65, Artesia, New Mexico 88210

3. Location of Well  
UNIT LETTER B 330 FEET FROM THE North LINE AND 1650 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 18S RANGE 28E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name  
Vandevanter

9. Well No.  
4

10. Field and Pool, or Wildcat  
Artesia

12. County  
Eddy

15. Elevation (Show whether DF, RT, GR, etc.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has 7" O.D. surface pipe set in 8" hole & cemented at 428' 5½" oil string set at 2500' in 6¼" to 6 3/8" hole & cemented 50 sax. T.D. 2550'. Perf. 2249' - 2255' & frac.  
Propose to set cast iron bridge plug at 2200' in 5½" casing & dump 35' cement on top of plug.  
Determine free point of casing, cut pipe off - fill hole with mud. Pull 5½", spot 100' cement 50' in and 50' over casing stub & tag. Then, depending on where casing stub is, whether we put another 100' cement at 1200'.  
25 sax 585' - 685' - 35 sax 380' to 480' & tag.  
Mud between all cement plugs.  
Surface plug & 4" monument & clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W.E. Jeffers TITLE Owner DATE July 6-1981

APPROVED BY W.A. Gressitt TITLE SUPERVISOR, DISTRICT II DATE JUL 8 1981

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Plugging