Submit 3 Copies To Appropriate District Office	State of New Me	exico	Form C-103
District 1 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natu	ral Resources	Revised May 08, 2003 WELL API NO.
District II ON GERMATION DIVIGION		30-025-10750	
District III 1220 South St. Francis Dr.		5. Indicate Type of Lease STATE X FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV Santa Fe, NM 87505		6. State Oil & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505			
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			TEXAS STATE
1. Type of Well:			8. Well Number
Oil Well Gas Well Other			1 .
2. Name of Operator LANEXCO, INC.			9. OGRID Number 013046
3. Address of Operator			10. Pool name or Wildcat
1105 WEST KANSAS, JAL, NM 88252 JALMAT TANSILL YATES 7 R			JALMAT TANSILL YATES 7 RIVER
Unit Letter P: 660 feet from the SOUTH line and 330 feet from the EAST line			
Section 16 Township 23S Range 36E NMPM County 18LEA			
11. Elevation (Show whether DR, RKB, RT, GR, etc.)			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Date 200			
NOTICE OF IN			SEQUENT REPORT OF
PERFORM REMEDIAL WORK	PLUG AND ABANDON 🔯	REMEDIAL WOR	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRI	ILLING OPNS: PLUG AND ABANDONMENT
PULL OR ALTER CASING	MULTIPLE COMPLETION	CASING TEST AI	
OTHER:		OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date			
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.			
WELL DATA: 9 5/8" set at 225ft., 7" set at 3083ft. (200 sx cmt at@shoe			
perforated 1280ft. for 2nd stage-ran 200sx cmt) TD-3300 shot hole 3159-3289.			
PROPOSAL: Rig up plugging company. Pull existing tubing. Set 7" CIBP			
at 3000ft. ±Dump 35 ft. cmt on top. RIH with tubing, circulate			
the hole with 10# mud. POOH and spot 30 sx at salt section. Spot 30 sx at 1295'-1195'. Perforate and squeeze 50 sx. at			
308'-208' and tag. Spot 10 sx at 50' to surface. Cut off			
wellhe	ead and install dry	hole mark	ter. Remove all equipment.
This work will start as soon as the plugging company is available.			
I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
I hereby certify that the information above is true and complete to the best of my knowledge and belief. SIGNATURE RESIDENT FRESIDENT Type or print name ROBERT W. LANSFORD (This space for State use) APPPROVED BY LAW W. Wark OCHIED REPRESENTATIVE WOOD 18 2004			
Type or print name ROBERT W. LANSFORD Telephone No 505 - 395 - 3056			
(This space for State use)			
APPPROVED BY Lay W. Wink October DREP NOV 0 8 2004			
Conditions of approval, if any			

THE OIL CONSERVATION DIVISION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS.