Form 3160-5 (February 2005)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

HOBBS OCD

FORM APROVED OMB NO. 1004-0135 EXPIRES. March 31, 2007

SUNDRY NOTICES AND REPORTS ON WELLS				5. Lease Serial No.		
SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (API)) for such proposals				NM-68084		
abandoned well Use Form 3160-3 (APD) for such proposals				6 If Indian, Allottee		
SUBMIT IN TRIPLICATE RECEIVED				Z Hear CA Assessment News and No.		
				7. Unit or CA Agreement Name and No.		
1a. Type of Well Oil Well Gas Well Other				8 Well Name and No.		
2. Name of Operator					Verde 7 Federal 4	1
2. Name of Operator DEVON ENERGY PRODUCTION COMPANY, LP				9 API Well No		
3. Address and Telephone No					30-025- 3275 4.395	8/2
·						
20 N Broadway, Oklahoma City, Ok 73102-8260 405-235-3611				10 Field and Pool, or Exploratory		
Location of Well (Report location clearly and in accordance with Federal requirements)* F 7 T24S R32E				Mesa Verde Bone Spring 11 County or Parish State		
2130 FNE 1300 FVVE 1 7 1243 NOZE				The County of Fans		
				Lea	NM	
	APPROPRIATE BOX(s) TO INDIC			, OR OTHER DATA	١	
TYPE OS SUBMISSION TYPE OF ACTION					`	
✓ Notice of Intent	Acidize	Deepen	5	on (Start/Resume)	Water Shut-Off	f
Alter Casing Fracture Treat Reclaim					Well Integrity	
Subsequent Report Casing Repair New Construction Recom					✓ OtherAPD Exte	nsion
Final Abandonment Notice	Convert to Injection	Plug Back	Water D	arıly Abandon isnosal		
13 Describe Proposed of Completed Operations (Clearly	state all pertinent details, and give pertinent	dates, including estimated date of st	arting any pro	posed work and approxim		
deepen directionally or recomplete honzontally, give subsurf Bond No on file with BLM/BIA Required subsequent report						3 *
Form 3160-4 shall be filed once testing has been completed						
ready for final inspection)					PARKET	** .
Devon Energy Production Compa	ny L. P. respectfully reques	sts an extension of our	r approv	ed APD on $11/1$	L9/09.	1
•						٠,
		•				
•						
				an l	ì	-
			APPRO	OVED FOR 24	MONTH PERIO	ייי כי
			ENDIN	· · · · · · · · · · · · · · · · · · ·	0/12	
			ENDIN	IG		
				•		~
14. I hereby certify that the foregoing is true	and correct					
		L. d. A. D 44 3/00				1-
Signed	Name _	Judy A. Barnett X86 Regulatory Specialis		Date	9/14/2011	
		. togatatory operation			0/17/2011	वर्तर हि
(This space for Federal or State Office use)		FIELD MANAGER		n	IEC 2 0 2011	777
	MacDonell Title			Date	DEC 2 0 2011	
Conditions of approval, if any:		CARL SBAD FIELD OFFIC	CE			7

*See Instruction on Reverse Side

Kt

PECOS DISTRICT CONDITIONS OF APPROVAL

OPERATOR'S NAME: Devon Energy prod Co

LEASE NO.: NM68084

WELL NAME & NO.: Mesa Verde 7 Federal 4
SURFACE HOLE FOOTAGE: 2150' FNL & 1980' FWL

BOTTOM HOLE FOOTAGE

LOCATION: Section 7, T.24 S., R.32 E., NMPM

COUNTY: Lea County, New Mexico

TABLE OF CONTENTS

The previously approved Conditions of Approval for the approved APD dated 11/19/2009 still apply. Any additions to the originally approved COAs will be addressed below.

Special Requirements

Well Pad Dimensions

□ Drilling

H2S Onshore Order 6 requirements Logging requirements Pressure Control Waste Material and Fluids

I. SPECIAL REQUIREMENT(S)

Well Pad Dimensions:

Devon submitted a sundry for a well pad dimension change and it was approved on March 4, 2010. Devon is approved to construct a 300 x 300 feet pad for this well. See v-door stipulation on previously approved APD and COA.

II. DRILLING

A. DRILLING OPERATIONS REQUIREMENTS

The BLM is to be notified a minimum of 4 hours in advance for a representative to witness:

- a. Spudding well
- b. Setting and/or Cementing of all casing strings
- c. BOPE tests

⊠ Lea County

Call the Hobbs Field Station, 414 West Taylor, Hobbs NM 88240, (575) 393-3612

- 1. A Hydrogen Sulfide (H2S) Drilling Plan should be activated 500 feet prior to drilling into the Delaware formation. As a result, the Hydrogen Sulfide area must meet Onshore Order 6 requirements, which includes equipment and personnel/public protection items. If Hydrogen Sulfide is encountered, please provide measured values and formations to the BLM.
- 2. Unless the production casing has been run and cemented or the well has been properly plugged, the drilling rig shall not be removed from over the hole without prior approval. If the drilling rig is removed without approval an Incident of Non-Compliance will be written and will be a "Major" violation.
- 3. Floor controls are required for 3M or Greater systems. These controls will be on the rig floor, unobstructed, readily accessible to the driller and will be operational at all times during drilling and/or completion activities. Rig floor is defined as the area immediately around the rotary table; the area immediately above the substructure on which the draw works is located, this does not include the dog house or stairway area.
- 4. The record of the drilling rate along with the GR/N well log run from TD to surface shall be submitted to the BLM office as well as all other logs run on the borehole 30 days from completion. If available, a digital copy of the logs is to be submitted in addition to the paper copies. The Rustler top and top and bottom of Salt are to be recorded on the Completion Report.

B. CASING

Changes to the approved APD casing and cement program require submitting a sundry and receiving approval prior to work. Failure to obtain approval prior to work will result in an Incident of Non-Compliance being issued.

Centralizers required on surface casing per Onshore Order 2.III.B.1.f.

Wait on cement (WOC) time prior to drilling out for a primary cement job will be a minimum 18 hours for a water basin, 24 hours in the potash area, or 500 pounds compressive strength, whichever is greater for all casing strings. DURING THIS WOC TIME, NO DRILL PIPE, ETC. SHALL BE RUN IN THE HOLE. Provide compressive strengths including hours to reach required 500 pounds compressive strength prior to cementing each casing string. See individual casing strings for details regarding lead cement slurry requirements.

No pea gravel permitted for remedial or fall back remedial without prior authorization from the BLM engineer.

Possible water flows in the Salado, Castile, Delaware and Bone Springs. Possible lost circulation in the Delaware and Bone Springs.

- 1. The 11-3/4 inch surface casing shall be set at approximately 900 feet (a minimum of 25 feet into the Rustler Anhydrite and above the salt) and cemented to the surface.
 - a. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with surface log readout will be used or a cement bond log shall be run to verify the top of the cement. Temperature survey will be run a minimum of six hours after pumping cement and ideally between 8-10 hours after completing the cement job.
 - b. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry.
 - c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
 - d. If cement falls back, remedial action will be done prior to drilling out that string.
- 2. The minimum required fill of cement behind the 8-5/8 inch intermediate casing is: The casing is to be set in the Lamar Limestone.
 - ☐ Cement to surface. If cement does not circulate see B.1.a-d above.

Formation below the 8-5/8" shoe to be tested according to Onshore Order 2.III.B.1.i. Test to be done as a mud equivalency test using the mud weight necessary for the pore pressure of the formation below the shoe (not the mud weight required to prevent dissolving the salt formation) and the mud weight for the bottom of the hole. Report results to BLM office.

- 3. The minimum required fill of cement behind the 5-1/2 inch production casing is:
 - a. First stage to DV tool:
 - Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with second stage cement job. Operator should have plans as to how they will achieve circulation on the next stage.
 - b. Second stage above DV tool:
 - Cement should tie-back at least **500** feet into previous casing string. Operator shall provide method of verification.
- 4. If hardband drill pipe is rotated inside casing, returns will be monitored for metal. If metal is found in samples, drill pipe will be pulled and rubber protectors which have a larger diameter than the tool joints of the drill pipe will be installed prior to continuing drilling operations.

C. PRESSURE CONTROL

- All blowout preventer (BOP) and related equipment (BOPE) shall comply with well control requirements as described in Onshore Oil and Gas Order No. 2 and API RP 53 Sec. 17. A fill-up line shall be installed above the uppermost preventer per Onshore Order 2.III.A.2.a.iii.
- 2. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the surface casing shoe shall be 3000 (3M) psi. Operator is installing 5000 psi (5M) BOP/BOPE and using as a 3M system.
 - a. For surface casing only: If the BOP/BOPE is to be tested against casing, the wait on cement (WOC) time for that casing is to be met (see WOC statement at start of casing section). Independent service company required.
- 3. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the 8-5/8" intermediate casing shoe shall be 5000 (5M) psi. 5M system requires an HCR valve, remote kill line and annular to match. The remote kill line is to be installed prior to testing the system and tested to stack pressure.

- a. In a water basin, for all casing strings utilizing slips, these are to be set as soon as the crew and rig are ready and any fallback cement remediation has been done. The casing cut-off and BOP installation can be initiated four hours after installing the slips, which will be approximately six hours after bumping the plug. For those casing strings not using slips, the minimum wait time before cut-off is eight hours after bumping the plug. BOP/BOPE testing can begin after cut-off or once cement reaches 500 psi compressive strength (including lead when specified), whichever is greater. However, if the float does not hold, cut-off cannot be initiated until cement reaches 500 psi compressive strength (including lead when specified).
- b. The tests shall be done by an independent service company utilizing a test plug **not** a **cup** or **J-packer**. The operator also has the option of utilizing an independent tester to test without a plug (i.e. against the casing) pursuant to Onshore Order 2 with the pressure not to exceed 70% of the burst rating for the casing. Any test against the casing must meet the WOC time for water basin (18 hours) or potash (24 hours) or 500 pounds compressive strength, whichever is greater, prior to initiating the test (see casing segment as lead cement may be critical item).
- c. The results of the test shall be reported to the appropriate BLM office.
- d. All tests are required to be recorded on a calibrated test chart. A copy of the BOP/BOPE test chart and a copy of independent service company test will be submitted to the appropriate BLM office.
- e. The BOP/BOPE test shall include a low pressure test from 250 to 300 psi. The test will be held for a minimum of 10 minutes if test is done with a test plug and 30 minutes without a test plug.
- f. Effective November 1, 2008, no variances will be granted on reduced pressure tests on the surface casing and BOP/BOPE. Onshore Order 2 requirements will be in effect.

D. DRILL STEM TEST

If drill stem tests are performed, Onshore Order 2.III.D shall be followed.

E. WASTE MATERIAL AND FLUIDS

All waste (i.e. drilling fluids, trash, salts, chemicals, sewage, gray water, etc.) created as a result of drilling operations and completion operations shall be safely contained and disposed of properly at a waste disposal facility. No waste material or fluid shall be disposed of on the well location or surrounding area.

Porto-johns and trash containers will be on-location during fracturing operations or any other crew-intensive operations.

TMM 112111