

DISTRICT I

1625 N. French Dr., Hobbs NM 88240

DISTRICT II

1301 W. Grand Avenue, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

DISTRICT IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, New Mexico 87504-2088

Form C-103

Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-32625
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Yates Petroleum Corporation		6. State Oil & Gas Lease No. VA-2883
3. Address of Operator 105 South 4th Str., Artesia, NM 88210		7. Lease Name or Unit Agreement Name Button Up AYD State Com
4. Well Location Unit Letter C : 600 feet from the North line and 2305 feet from the West line Section 10 Township 9S Range 32E NMPM County Lea		8. Well No. 1
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4444' GR		9. Pool Name or Wildcat Wildcat Canyon

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Propose to plug and abandon as follows:

- 1) RU safety trailer, kill well, NDWH and NU BOP.
- 2) Set CIBP @ 9900' and dump 35' cement on plug.
- 3) Circulate hole w/9.5# mud-laden fluid.
- 4) Perforate squeeze holes @ 6300'. WOC and tag.
- 5) Pump 70 sx cement to place plug inside and outside casing 6300-6200'.
- 6) Perforate squeeze holes @ 3756'.
- 7) Pump 70 sx cement to place plug inside and outside casing 3756-3656'. WOC and tag.
- 8) Spot 25 sx plug 2334-2234'.
- 9) Perforate squeeze holes @ 451'. Place 25 sx plug inside and outside casing 451-351'. WOC and tag.
- 10) Place 10 sx plug @ surface.
- 11) Cut off head, weld on plate and install marker. Clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

SIGNATURE Stormi Davis TITLE Regulatory Compliance Technician DATE 6/19/03

Type or print name Stormi Davis Telephone No. 505-748-1471

(This space for State use)

APPROVED BY

Conditions of approval, if any:

ORIGINAL SIGNED BY

GARY W. WINK

OC FIELD REPRESENTATIVE II/STAFF MANAGER

JUN 24 2003