

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources
OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised August 1, 2011

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Chevron USA INC MIDCONTINENT, L.P.

3. Address of Operator
6301 DEAUVILLE BLVD., MIDLAND, TX 79706

4. Well Location; Surface
Unit Letter I : 1830 feet from the South line and 600 feet from the East line
Section 1 Township 17S Range 5E NMPM County Lea

11. Elevation (Show whether DR, RKB, R, etc.)
3929' G

12. Check Appropriate Box to Indicate Nature of Notice Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

SUBSEQUENT R'

REMEDIAL WORK ☐
COMMENCE DRILLING OPERATIONS ☐
CASING/CEMENT JOB ☐

INT TO PA PMX
P&A NR
P&A R

OTHER: ☐

OTHER: ☐ TEMPORARILY

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or completion. 1 3/8" 48# @ 466' TOC surface, 8 5/8" 32# @ 5200' TOC surface, 5 1/2" 17# & 15 1/2" set @ 10,955' TOC 4815' TOC 4815'

Chevron USA INC respectfully request to abandon this well as follows:

1. MIBU, PU HOPE, HOOH with all tubing if present
2. Tag CIBL at 1660', place a 20 sx CL "H" cement from 8660'-8625', circ well with 4.5 pl salt gel med. 1st csg
3. PU to 6208', place a 30 sx CL "C" cement plug from 6208'-6200' (Gloria)
4. PU to 5250', place a 30 sx CL "C" cement plug from 5250'-5050' (8 5/8" shoe). TAG TO 4725' OR BETTER
5. PU to 4683', place a 60 sx CL "C" cement plug from 4683'-4700' (San Andres, Grayburg).
6. PU to 3132', place a 30 sx CL "C" cement plug from 3132'-2982' (base of Salt, VOC and tag.
7. PU to 2098', place a 50 sx CL "C" cement plug from 2098'-1700' (Top Salt, Rustler) and tag.
8. PU to 516', perf and sqz 100 sx CL "C" cement plug from 516' to surface (1 3/8" shoe).
9. Cut all casings & anchors & remove 3' below grade. Weld on dry hole marker. Clean location.
10. All cement plugs class "C" with closed loop system used. VERIFY CMT TO SURFACE ALL STRINGS

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Ricky Spiller TITLE Engineer DATE 7/10/17

Type or print name Ricky Spiller E-mail address: rcspiller@chevron.com PHONE: (432) 687-7479

For State Use Only

APPROVED BY: Manuel Litcher TITLE Petroleum Engr. Specialist DATE 07/12/2017

Conditions of Approval (if any):

7/31/2017
PLUGGING CREW
IN AREA. WELL WILL BE P/A'd BY 9/3/2017
MTR

NOTIFY OCD 24 HOURS PRIOR TO
BEGINNING PLUGGING OPERATIONS