

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Pronghorn Mgt. Corp.

3. Address and Telephone No.

P.O. Box 1772 Hobbs, N.M. 88240 505-392-2495

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990 FNL + 1980' FEL

519-T235-R33E

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

LC-068848

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

MARSHALL FED #6

9. API Well No.

30-025-25151

10. Field and Pool, or Exploratory Area

Cruz Delaware

11. County or Parish, State

LEA

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Move in p + a equipment. Poot w/ production equipment.

2. Set C.I.B.P. @ $\pm$ 4950'. Cap w/ 35' cement

3. Circulate hole w/ mod laden fluid.

4. Nipple up to 5 1/2", K-55, 14 # csg.

Stretch, cut, and pull $\pm$ 3500' casing.

5. Set 100' plug in and out of 5 1/2" stub - Tag

6. Set 100' plug 1195' - 1245' - 8 5/8" shoe - Tag

7. Set surface plug. Cut off well head.

8. Install day hole marker. Clean location.

* Mod laden fluid between all plugs

SEP - 7 2005

GARY GOURLEY
PETROLEUM ENGINEER

14. I hereby certify that the foregoing is true and correct

Signed M. Baker

Title Partner

Date 08/24/05

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date