

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.

30-0-25-25193

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

K-3218

7. Lease Name or Unit Agreement Name

LARIO STATE #1

8. Well Number

#1

9. OGRID Number

153427

10. Pool name or Wildcat

BAR "N" PENN

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

GUADALUPE OPERATING L.L.P.

3. Address of Operator

1407 W. CUTHBERT AVE MIDLAND, TX 79701

4. Well Location

Unit Letter O : 660 feet from the SOUTH line and 1,874 feet from the EAST line

Section 1

Township 9S

Range 32E

NMPM

County LEA

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

4407 GL

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____

Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☒
COMMENCE DRILLING OPNS. ☐ Packer ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram showing proposed completion or recompletion.

1. Set CIBP at 9100' & dump bail 25 sx cmt on top.
2. Set 100' cmt plug (125 sx) 5900' - 6000'.
3. Perforate 5 1/2" csg at 3700' & squeeze cmt 8 5/8" shoe using 100 sx cmt and packer. Set packer at 3600' & leave 50' of cmt inside of 5 1/2" csg. Wait 4 Hrs & tag. Re-squeeze as needed.
4. Set 125 sx cmt plug 1950' - 1850'. Do not tag.
5. Perforate 5 1/2" csg at 474'. Attempt to pump into formation. If cannot pump - in, set 10 sx surface cmt plug. If can pump - in, pump 125 sx cmt plug 474' - 374'. Tag this plug. And then set 10 sx surface cmt plug.
6. This procedure is assuming cannot recover any 5 1/2" csg. If able to recover csg, set 50' of cmt inside 5 1/2" stub & 50' out of stub. Woc & tag.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE

TITLE MANAGING PARTNER

DATE 1-28-07

Type or print name John Breedlove

E-mail address: JBREED1313@AOL.com

Phone No. 432-686-8632

For State Use Only

APPROVED BY: Ray W. Wink

Conditions of Approval (if any):

TITLE FIELD REPRESENTATIVE II/STAFF MANAGER

FEB 1 2007
DATE