

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S St Francis Dr, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-05097

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name
New Mexico State 'C'

8. Well Number 2

9. OGRID Number

10. Pool name or Wildcat
King Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator Paladin Energy Corp.

3. Address of Operator 10290 Monroe Dr., Suite 301
Dallas, Texas 75229

4. Well Location

Unit Letter D : 990 feet from the North line and 440 feet from the West line
Section 36 Township 13S Range 37E NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3843' GR

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type Steel Tank Depth to Groundwater 60 Distance from nearest fresh water well 1 mile Distance from nearest surface water 1 mile +

Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPEN ☐ PLUG AND ABANDON ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 1.) MIRU, GIH with tubing and packer, set packer at 7,300' (+,-), pump 320 sacks of cement and fill casing down CIBP at 10,100' covering perfs from 9,232-392'. POOH with packer and tubing.
- 2.) GBIH with tubing and set a 100' cement plug from 6,400-6,500', POOH with tubing, WOC.
- 3.) Perforate hole in 5-1/2" casing at 4,550' (+,-). GIH w/ 2-7/8" tubing and set 3rd 100' cement plug from 4,550' 4,650' with 50 sacks cement. WOC. Tag plug.
- 4.) Perforate hole in 5-1/2" casing at 1,600' (+,-), pump 50 sks class H cement. Spot plug from 1,600' to 1,700'. WOC. Tag plug.
- 5.) Pull up with workstring, EOT at 250', pump 50 sks class H cement. Spot plug from 350' to 250'. WOC. Tag plug. Spot surface plug from 0 to 60'. Cut Casing 3' below mud line. Backfill and clear location.

Place P & A marker and move off location.

**THE OIL CONSERVATION DIVISION MUST
BE NOTIFIED 24 HOURS PRIOR TO THE
BEGINNING OF PLUGGING OPERATIONS.**

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Dan H. Hobbs TITLE VP Exploration & Production DATE 10/15/2006

Type or print name
For State Use Only

E-mail address:

Telephone No.

APPROVED BY: Larry W. Wink TITLE OC FIELD REPRESENTATIVE II/STAFF MANAGER DATE OCT 22 2007

Conditions of Approval (if any):