

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
May 27, 2004

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-025-11183
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name JF Black
8. Well Number #3
9. OGRID Number State Plugging
10. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS)

1. Type of Well: Oil Well ☒ X Gas Well ☐ Other

2. Name of Operator  
State of NM formerly Pronghorn

3. Address of Operator  
1625 N. French Dr. Hobbs, NM 88240

4. Well Location  
Unit Letter F : 1980 feet from the N line and 1980 feet from the W line  
Section 21 Township 24S Range 37E NMPM County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water

Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ X  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

TVD 3617 13" 40# csg set at 192' Cemented w/50 sxs  
8-5/8" 28# set at 1369' ELW Cemented w/100 sxs  
7" 24# set at 3379' Cemented w/125 sxs  
Open hole with Nitro- Packer ?

- 1) Set CIBP at 3200'. Dump bail 35' of cement on top
  - 2) Perf at 2600' squeeze 50' of cement inside and 50' outside. TAG
  - 3) Perf at 1350' squeeze 50' of cement inside and 50' outside. TAG
  - 4) Perf at 200' squeeze cement to surface. Leave 50' inside casing. TAG
  - 5) Place 10 sxs of 60' plug whichever greater in 13" to surface.
- Circulate mud laden fluid between plugs with 12.5 lb/ gal salt gel.

RECEIVED

MAR 17 2008

HOBBS OCD

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Chris Williams TITLE Dist. Sup DATE 3/17/08

Type or print name  
For State Use Only

E-mail address:

Telephone No.

APPROVED BY: Chris Williams TITLE Dist. Sup DATE 3/17/08

Conditions of Approval (if any):