

Submit 1 Copy To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources  
OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
October 13, 2009

WELL API NO. 30-025-20724
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. 15603
7. Lease Name or Unit Agreement Name LOWE
8. Well Number 1
9. OGRID Number 131559
10. Pool name or Wildcat Gladiola Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator PURVIS OPERATING CO.	
3. Address of Operator PO BOX 51990, MIDLAND, TX 79710-1990	
4. Well Location Unit Letter <u>A</u> : <u>554</u> feet from the <u>North</u> line and <u>554</u> feet from the <u>East</u> line Section <u>34</u> Township <u>12S</u> Range <u>37E</u> NMPM Lea County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3901 GR	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Run CIBP to 9100' on wireline and set. Dump bail 20' of cement on top of CIBP.
2. Run tbg to 9100' and circulate hole with mud laden fluid. Spot 100' cement plug @ 6300'
3. Run free point and cut off 5 1/2" csg at approx. 6000' and pull. Spot 50 sks cement (50' outside and 50' inside of cut off).
4. Spot 50 sks cement at intermediate shoe from 4531' back to 4431'.
5. Cut off 8 5/8" csg at 2700'. Set 100 sk cement plug from 2750' back to 2650'. Spot 100' cement plug @ 1950'
6. Set 100 sks cement at surface shoe from 398' back to 298'.
7. Set 20 sk surface plug. Cement to 3' from surface.
8. Install dry hole marker.

The Oil Conservation Division **Must be notified 24 hours prior** to the beginning of plugging operations.

Spud Date:

August 20, 1964

Rig Release Date:

October 19, 1964

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Donnie E. Brown*

TITLE

Petroleum Engineer

DATE: October 21, 2010

Type or print name Donnie E. Brown

E-mail address: eng@purvisop.com

PHONE: 432-682-7346

For State Use Only

APPROVED BY:

*E. Brown*

TITLE

STATE MGR

DATE 10-26-10

Conditions of Approval (if any):

# PURVIS OPERATING CO.

OGRID: 131559

LOWE #1

Lease No. 15603, Lea County, NM

