

Submit 1 Copy To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
October 13, 2009

<b>RECEIVED</b> <b>APR 04 2011</b> <b>HOBBSUCD</b>		WELL API NO. 30-041-20505 ✓	
CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	
		6. State Oil & Gas Lease No. NM 23018	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name FEDERAL J ✓	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other <input type="checkbox"/>		8. Well Number 1 ✓	
2. Name of Operator H.L. Brown Operating, LLC		9. OGRID Number 213179 ✓	
3. Address of Operator 300 W Louisiana Midland Texas 79702		10. Pool name or Wildcat BLUITT SAN ANDRES - GAS	
4. Well Location Unit Letter <u>G</u> : <u>1650</u> feet from the <u>NORTH</u> line and <u>1650</u> feet from the <u>EAST</u> line ✓ Section <u>10</u> Township <u>85</u> Range <u>37-E</u> NMPM County <u>ROOSEVELT</u>			
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4039' KB 4052' (13' KB)			

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. PULL AND LAY RODS DOWN
2. PULL OUT OF HOLE WITH TUBING
3. SET CIBP @ 4450' WITH 35' CEMENT ON TOP
4. CUT AND PULL 3800' OF 4 1/2" CASING
5. RUN TUBING AND SET 100' CEMENT PLUG, (40 SKS) ACROSS 8 5/8" CASING SHOE. 3816'-3716', TAG
6. LAY DOWN EXCESS TUBING
7. SET 100' CEMENT PLUG 2100'-2000' (40 SKS), TAG
8. LAY DOWN EXCESS TUBING
9. SET 100' CEMENT PLUG ACROSS 12 3/4" CASING SHOE 531'-431', TAG.
10. LAY DOWN EXCESS TUBING
11. SET 10' SURFACE PLUG 3'-13'
12. CUT OFF WELL HEADS, CAP, INSTAL MARKER.
13. REMOVE ALL EQUIPMENT, RESTORE LOCATION.

Spud Date:

As soon as rig is  
available - April 2011

Rig Release Date:

4 - 11

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Steve Treichmann*

TITLE

Oper Supt

DATE

3/31/11

Type or print name

STEVE TREICHMANN

mail address:

SJT@HIBOPERATION

PHONE:

432-683-5216

For State Use Only

APPROVED BY

*[Signature]*

TITLE

Staff

DATE

6-6-2011

Conditions of Approval (if any):