

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-85

SUNDRY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- SALT WATER DISPOSAL		5. State Oil & Gas Lease No.
Name of Operator Amerada Hess Corporation		7. Unit Agreement Name
Address of Operator Drawer D, Monument, N.M. 88265		8. Farm or Lease Name East Caprock S.W.D.
Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 11 TOWNSHIP 12-S RANGE 32-E N.M.P.M.		9. Well No. 4
		10. Field and Pool, or Wildcat Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 4350' DF		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER Temporarily Abandon. <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to perf. stuck 2-7/8" tbg. above top of fill inside tbg. @ approx. 10,700'. Run 1-1/2" tbg. inside 2-7/8" tbg. & spot cement plug between 2-7/8" tbg. & 5-1/2" csg.. Run free point indicator & cut off 2-7/8" tbg. above stuck tbg. Spot 100' of cement @ top of cut off 2-7/8" tbg.. Load hole w/mud & spot 100' cement plug inside 5-1/2" csg. @ top of Glorieta zone @ 5043'. Spot 100' cement plug inside 5-1/2" csg. @ base of salt @ 2140'. Spot 100' cement plug inside 5-1/2" csg. @ top of salt @ 1523'. Spot 100' cement @ surface. Install well head & temporarily abandon.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>E.B. Fisher</u>	TITLE <u>Supervisor Admin. Svc.</u>	DATE <u>5-21-81</u>
APPROVED BY <u>[Signature]</u> TITLE <u>[Signature]</u> DATE <u>MAY 20 1981</u>		
CONDITIONS OF APPROVAL, IF ANY:		