

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.
------------------------------

--

7. Unit Agreement Name	#1
No. Caprock Queen Unit	

8. Farm or Lease Name	
No. Caprock Queen	

9. Well No.	
Tract 4, Well No. 13	

10. Field and Pool, or Wildcat	
Caprock Queen (Lea)	

--

12. County	
Lea	

--

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
--

2. Name of Operator	Thunderbird Oil Corporation
---------------------	-----------------------------

3. Address of Operator	P. O. Box 1778, Midland, Texas 79701
------------------------	--------------------------------------

4. Location of Well	UNIT LETTER M 660 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 31 TOWNSHIP 12-S RANGE 32-E NMPM.
---------------------	---

--

15. Elevation (Show whether DF, RT, GR, etc.)	4388' GL
---	----------

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
--

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
--

8-5/8" @ 255' w/125 sx.  
5-1/2" @ 2956' w/600 sx.  
Open hole @ 2956-3014'  
Top of Cement @ 840' by temperature survey.

1. Displace hole with salt base mud. - 2500# DEN 100 6615
2. Set CIBP @ 2850'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off & pull 5-1/2" casing @ approx. 840'.
5. Spot 35 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" surface casing @ 205-305'.
7. Spot 10 sx. cement plug @ surface and erect 4-1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

NOTIFY Commission 24 hrs prior to setting plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mary E. Schwan	TITLE President	DATE Dec. 20, 1974
-----------------------	-----------------	--------------------

APPROVED BY	TITLE	DATE

CONDITIONS OF APPROVAL, IF ANY: