

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
(SEE "APPLICATION FOR PERMIT" FORM C-101 FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name No. 1 No. Caprock Queen Unit
2. Name of Operator Thunderbird Oil Corporation	8. Farm or Lease Name No. 1 No. Caprock Queen Unit
3. Address of Operator P. O. Box 1778, Midland, Texas 79701	9. Well No. Tract 3, Well No. 5
4. Location of Well UNIT LETTER E 1980 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 31 TOWNSHIP 12-S RANGE 32-E N.M.P.M.	10. Field and Pool, or Wildcat Caprock Queen (Lea)
11. Elevation (Show whether DE, RT, GR, etc.) 4390' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-5/8" @ 238' w/125 sx.
5-1/2" @ 2973' w/600 sx.
Well completed open hole 2997-3024'.

1. Displace hole with salt base mud.
2. Set CIBP @ 2900'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off & pull 5-1/2" casing @ approximately 800'.
5. Spot 25 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" surface casing @ 181-295'.
7. Spot 10 sx. cement plug @ surface and erect 4-1/2" regulation dry hole marker.
8. Clean up location for N.M.O.C.C. inspection and approval.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Harry J. Schum TITLE President DATE 12-3-74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

DEC 1 1964

OIL CONSERVATION COMM.
WASH. D. C.