

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- SWD		7. Unit Agreement Name	
2. Name of Operator Amerada Hess Corporation		8. Farm or Lease Name Bagley SWD	
3. Address of Operator Drawer D, Monument, New Mexico 88265		9. Well No. /	
4. Location of Well UNIT LETTER <u>N</u> <u>1980</u> FEET FROM THE <u>West</u> LINE AND <u>560</u> FEET FROM THE <u>South</u> LINE, SECTION <u>2</u> TOWNSHIP <u>12-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat Bagley Penn.	
15. Elevation (Show whether DF, RT, GR, etc.) 4250 DF		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to pull tbg., set cement retainer in 5½" csg. at 6445', squeeze 5½" csg. perf. fr. 9045' to 9090' & open hole fr. 9100' to 9230', leaving at least 35' of cement on top of retainer. Load hole w/10# salt gel mud. Cut off 5½" csg. at approx. 5700', pull and lay down. Spot cement 50' in & 50' out of top of cut off 5½" csg., spot 100' cement across Glorieta zone @ 5150', spot cement 50' in and 50' out of bottom of 8-5/8" csg., spot 100' cement across top of salt at 1840', spot 10 sks. cement at top of 8-5/8" csg. cut off csg. head, set dry hole marker.

RECEIVED 24
OCT 19 1979
SANTA FE, N.M.
FOR THE C-103

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>EB Fisher</u>	TITLE <u>Supv. Adm. Ser.</u>	DATE <u>10-16-79</u>
APPROVED BY <u>Jerry Sexton</u>	TITLE <u>Dist 1, Supv.</u>	DATE <u>OCT 19 1979</u>
CONDITIONS OF APPROVAL, IF ANY:		