

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN THE
(Other Instruct.
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a well. Use "APPLICATION FOR PERMIT" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LC-060581

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

J. T. Caudle

9. WELL NO.

4

10. FIELD AND POOL, OR WILDCAT

Bagley - Penn.

11. SEC., T., R., M., OR BLK. AND SURVEY OF AREA

Sec. 3, T12S, R33E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☐ OTHER TA

2. NAME OF OPERATOR

Amerada Hess Corporation

3. ADDRESS OF OPERATOR

Drawer D, Monument, New Mexico 88265

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

1980' FEL & 660' FSL

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, OR, etc.)

4257' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to MIRU pulling unit, pick up 5-1/2" csg., calculate stretch, & calculate free point. TIH w/csg. cutter & cut csg. 100' above free point. Pull & lay down 5-1/2" csg. Circ. hole w/mud. Pull up & spot 100' cement plug across 5-1/2" stub. Pull & spot 100' cement plug across intermediate shoe fr. 3740' - 3840' & TOH. Perf. 8-5/8" csg. at 320'. Pump 50 sks. cement out perforation & leave 20 sks. inside csg. Spot 10 sks. cement at surface. Remove well head, install dry hole marker & clean location.

* RESTORE LOCATION

* NOTIFY BLM -

SEP 23 11 42 AM '89
OCT 1 1989

RECEIVED

18. I hereby certify that the foregoing is true and correct

SIGNED R. L. Whelan

TITLE Supv. Adm. Svc.

DATE 9-22-89

(This space for Federal or State office use)

APPROVED BY Adam Salameh

TITLE Supv. Adm. Svc.

DATE 10/3/89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side