

NO. OF COPIES RECEIVED		
DISTRIBUTION		
AMT A FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR NOTICES TO ABANDON OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO (1) OPEN, (2) CLOSE, (3) PLUG BACK, OR (4) RE-OPEN.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator
Southland Royalty Company

Address of Operator
21 Desta Drive, Midland, Texas 79705

Location of Well
UNIT LETTER A 660 FEET FROM THE North LINE AND 810 FEET FROM
THE East LINE, SECTION 13 TOWNSHIP 11S RANGE 33E N.M.P.M.

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

7. Unit Agreement Name

8. Farm or Lease Name
Farrar "A"

9. Well No.
1

10. Field and Pool, or Wildcat
Inbe (Permo-Penn)

12. County
Lea

11. Elevation (Show whether DF, RT, GR, etc.)
4202' GR

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MI csg pulling rig. LD rods. Pull tbg.
2. Set BP on WL @ 9430'. Spot 35' cmt plug w/bailer @ 9359-9430'.
3. Load hole w/mud laden fluid.
4. Find free point of 5 1/2" csg & cut (+ 5500'). POH. POH & LD 5 1/2" csg.
5. Spot 100' cmt plug, 50' in & out of 5 1/2" stub. WOC. Tag top cmt.
6. Spot 100' cmt plug, 50' in & out of 8 5/8" csg shoe @ 3970'. WOC. Tag top cmt. POH.
7. Find free point of 8 5/8" csg & cut (+ 1500'). POH. LD 8 5/8" csg.
8. RIH & spot 100' cmt plug, 50' in & out of 8 5/8" csg stub. WOC. Tag top cmt.
9. Spot 100' cmt plug, 50' in & out of 13 3/8" csg shoe @ 365'. WOC. Tag top cmt.
0. Spot 10 sx cmt plug @ surf.
1. Install dry hole marker, clean up location & remove battery.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Stark TITLE Operations Engineer DATE 5/16/84

ORIGINAL SIGNED BY JAMES SEXTON
APPROVED BY DISTRICT 1 SUPERVISOR TITLE _____ DATE MAY 18 1984

CONDITIONS OF APPROVAL, IF ANY: