

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	K2653

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name New Mexico State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 1
4. Location of Well UNIT LETTER N , 1975.8 FEET FROM THE West LINE AND 660 FEET FROM THE South LINE, SECTION 2 TOWNSHIP 11-S RANGE 33E NMPM.	10. Field and Pool, or Wildcat N. E. Bagley, Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 4237 Gr.	12. County Lee

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Spot 20 ex cement plug over casing perforations 8872 - 8882 using 10# mud as displacing medium through 2" EUE tubing.
A 20 ex cement plug will be similarly spotted at 7400' (Top of Abo).
Cut off 5-1/2" casing at approximately 5105 and pull.
Spot 20 ex cement plug at 5100' (Top casing stub and top Glorieta).
Spot 20 ex cement plug at 3825' (Bottom of 8-5/8" casing and Top of San Andres).
Cut off 8-5/8" casing at approximately 860' and pull.
Spot 20 ex cement plug at 860' (Top of 8-5/8" casing stub).
Spot 20 ex cement plug at 370' (Bottom of 13-3/8" casing).
Place 10 ex plug in top of 13-3/8" casing and set 4" pipe marker.

Proposed starting date: Approximately December 5, 1968

JCC/jg

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. G. Whitten TITLE District Mgr. of Production DATE November 25, 1968

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: