

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
		5. State Oil & Gas Lease No. -
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		7. Unit Agreement Name -
2. Name of Operator Charles B. Read		8. Farm or Lease Name Ainsworth
3. Address of Operator P. O. Box 2126, Roswell, New Mexico 88201		9. Well No. 1
4. Location of Well UNIT LETTER H 1980 FEET FROM THE North LINE AND 510 FEET FROM THE East LINE, SECTION 19 TOWNSHIP 9S RANGE 34E NMPM.		10. Field and Pool, or Wildcat Vada Penn.
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

In accordance with our telephone conversation on March 18, 1968 we propose to plug and abandon the above well in the following manner:

1. Run 2-3/8" tubing to 9800 and set 25 sack plug @ 9800' to 9600'.
2. Fill hole with good mud and pull tubing.
3. Cut and remove 5-1/2" casing @ 8200'.
4. Cut and remove 8-5/8" casing @ 750'.
5. Set 25 sack plug 8250' to 8150'.
 - " 25 " " 6875' to 6775'.
 - " " " " 5400' to 5300'.
 - " " " " 4075' to 3975'.
 - " " " " 800' to 700'.
 - " " " " 400' to 350'.
- Set 10 sack surface plug 10'-0'.
6. Put up regulation marker.
7. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles B. Read TITLE Operator DATE March 21, 1968

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: