

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
K-4104

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REELEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - FORM C-101 FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name State "K"
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of well UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 2 TOWNSHIP 10-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4241' RDB	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

Move in service unit. Run in hole with CIBP and set at 9600'. Pressure test CIBP to 500 PSI. Cap with 35' of cement. Run freepoint survey and cut 5 1/2" casing 100' above freepoint. Pull 5 1/2" casing. Spot a 50 sack cement plug across the 5 1/2" casing stub. Pull up and spot a 25 sack cement plug across the 8-5/8" casing shoe at 4016'. Run freepoint and cut 8-5/8" casing 100' above freepoint. Pull 8-5/8" casing. Spot a 50 sack cement plug across the 8-5/8" casing stub. Spot 50 sack plug across 11-3/4" casing shoe at 334'. Spot a 10 sack plug at surface. Weld on cap and erect PXA marker. (Spot plugging mud between all plugs.)

0+5-NMOCD,H 1-HOU 1-DMF 1-W. Stafford, HOU

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mark Freeman TITLE Assist. Admin. Analyst DATE 12-17-82

APPROVED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE DEC 21 1982