

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

| | |
|---|------------------------------|
| 5a. Indicate Type of Lease | |
| State <input checked="" type="checkbox"/> | Fee <input type="checkbox"/> |
| 5. State Oil & Gas Lease No. | |
| K-3507 | |

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | | |
|--|--|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> | | 7. Unit Agreement Name |
| 2. Name of Operator BTA Oil Producers | | 8. Farm or Lease Name Anderson "A" 676 Ltd. |
| 3. Address of Operator 104 South Pecos, Midland, Texas 79701 | | 9. Well No. 3 |
| 4. Location of Well UNIT LETTER "K" 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 6 TOWNSHIP 10-S RANGE 34-E NMPM. | | 10. Field and Pool, or Wildcat Vada-Penn |
| 15. Elevation (Show whether DF, RT, GR, etc.) 4255' GL | | 12. County Lea |

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Procedure:

Notify NMOCC, Hobbs 24 hrs before plugging operations commence
Set CIBP @ 9700' w/3 sx (35') cmt on top
Cut & pull 5½" csg - Top cmt @ 8254'
35 sx @ 5½" stub
35 sx @ 5416' (Glorietta)
50 sx @ 4012' (8-5/8" shoe)
Cut & pull 8-5/8" csg
50 sx @ 8-5/8" stub
50 sx @ 380' (12-3/4" shoe)
10 sx @ surface
Mud laden fluid between plugs
Install dry hole marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L. H. Boyce TITLE Production Clerk DATE 3/29/72

APPROVED BY John Runyan TITLE Geologist DATE MAR 31 1972
CONDITIONS OF APPROVAL, IF ANY: