

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Sun Oil Company		5. State Oil & Gas Lease No. L-196 & K-2519
3. Address of Operator P. O. Box 1861 Midland, Texas 79701		7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>L</u> <u>760</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>4</u> TOWNSHIP <u>11 S</u> RANGE <u>34 E</u> NMPM.		8. Farm or Lease Name N.M. "N" St. Oil Com.
		9. Well No. 1
		10. Field and Pool, or Wildcat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4214 DF		12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging operations to begin approximately 5-27-71 as follows:

1. Fill hole with 9.5# mud.
2. Shoot 2 7/8" tubing at point of casing collapse, approx. 4500'.
3. Spot 50 sack plug on top of collapsed casing.
4. Shoot and pull 5 1/2" casing from 4000'.
5. Spot 100 ft. plugs in and out of 5 1/2" casing stub, in and out of 8 5/8" casing shoe 3980-4080.
6. Locate free point, shoot and pull 8 5/8" casing.
7. Spot 100 sack plug in and out 8 5/8" casing stub, at 2685-2785, 1910-2010, 350-450, 10 sacks @ surface.
8. Set marker, clear location and level all pits.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Proration Clerk DATE 4-30-71
APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT DATE MAY 3 1971
CONDITIONS OF APPROVAL, IF ANY: