

OF COPIES RECEIVED		
DISTRIBUTION		
STATE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator READ & STEVENS, INC.	8. Farm or Lease Name Ainsworth
3. Address of Operator P. O. Box 2126, Roswell, New Mexico 88201	9. Well No. 2
4. Location of Well UNIT LETTER P 554 FEET FROM THE South LINE AND 554 FEET FROM THE East LINE, SECTION 19 TOWNSHIP 9-South RANGE 34-East NMPM.	10. Field and Pool, or Wildcat Vada Penn.
11. Elevation (Show whether DF, RT, GR, etc.) 4297.6' GR - 4308.6' RKB	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 9890' 1m. w/ perforations @ 9816'-9824'. Propose to plug & abandon as follows:

1. Circulate hole full of good mud.
2. Set cast iron bridge plug above perfs. @ 9800' & spot 35' cement plug on top of bridge plug.
3. Cut & pull 5 1/2" casing where free. Top of cement behind 5 1/4" is at 7220'.
4. Spot 100' cement plug 1/2 in & 1/2 out of 5 1/2" casing stub.
5. Spot 100' cement plug @ top of Glorieta @ 5412'.
6. Spot 100' cement plug 1/2 in & 1/2 out of 8 5/8" casing shoe @ 4010'.
7. Cut & pull 8 5/8" casing where free & spot 100' cement plug 1/2 in & 1/2 out of 8 5/8" casing stub.
8. Spot 100' cement plug @ base of Salt @ 2560'.
9. Spot 100' cement plug @ top of Salt @ 2160'.
10. Spot 100' cement plug 1/2 in & 1/2 out of 12 3/4" casing shoe @ 400'.
11. Spot 10 sx. cement plug at surface & install regulation marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103

Expires 7/1/77

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>Jerry Lenton</i>	TITLE Agent	DATE 6-28-76
APPROVED BY <i>Jerry Lenton</i>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		