

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Free <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5082

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator MONSANTO COMPANY	8. Farm or Lease Name TUC STATE
3. Address of Operator 101 North Marienfeld, Midland, Texas 79701	9. Well No. /
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>30</u> TOWNSHIP <u>10S</u> RANGE <u>34E</u> N.M.P.M.	10. Field and Pool, or Wildcat Vada (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4241' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This oil well is depleted; request is made to plug and abandon as follows:

Set C.I. Bridge plug at 9900' above perforations 9949-66' w/ 35' cement plug on top.
Displace hole w/ 10.5# Mud.
Shoot off 5½" casing above top cement and pull.
Set 100' plug in stub.
Spot 100' plugs across top of Abo at 7759' and Glorieta at 5472' formations, if not behind pipe.
Set 100' cement plug at base 8 5/8" casing at 3981'.
Shoot off 8 5/8" casing above top cement and pull; set 100' cement plug in stub.
Set 100' cement plug at base 11 3/4" casing at 362'.
Set 10 Sx plug in 11 3/4" casing at surface w/ 4" pipe marker at surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. W. Wood TITLE District Production Mgr. DATE January 9, 1973

Orig. Signed by
Joe D. Ramey
Dist. I. Supv.

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____ DATE _____

JAN 15 1973