

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. K 2443	
7. Unit Agreement Name	
8. Farm or Lease Name MGF "A" State	
9. Well No. 1	
10. Field and Pool, or Wildcat Vada (Penn)	
12. County Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator  
MONSANTO COMPANY

3. Address of Operator  
101 North Marienfeld, Midland, Texas 79701

4. Location of Well  
UNIT LETTER J, 2080 FEET FROM THE South LINE AND 2080 FEET FROM THE East LINE, SECTION 30 TOWNSHIP 10S RANGE 34E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)  
4256' RKB

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This oil well is depleted; request is made to plug and abandon as follows:

Set C.I. bridge plug at 9850' above perforations 9889-10,009' w/ 35' cement plug on top. Displace hole w/ 10.5# mud.  
Shoot off 5 1/2" casing above top cement and pull. Set 100' cement plug in stub.  
Set 100' cement plug at base of 8 5/8" casing at 3983'.  
Shoot off 8 5/8" casing above top cement and pull. Set 100' cement plug in stub.  
Set 100' cement plug at base 11 3/4" casing at 363'.  
Set 10 Sx plug in 11 3/4" casing at surface w/ 4" pipe marker at surface.

*→ Spot 100' plugs across top of Abot Horietz formations if not behind pipe.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. W. Wood TITLE District Production Manager DATE 4/18/72

APPROVED BY John Runyan TITLE Geologist DATE APR 20 1972

CONDITIONS OF APPROVAL, IF ANY: