

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-196 & K-2519	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" - (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sun Oil Company	8. Farm or Lease Name N.M. "N" St. Oil Com.
3. Address of Operator P. O. Box 1861 Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER <u>K</u> , <u>760</u> FEET FROM THE <u>North</u> LINE AND <u>1981</u> FEET FROM THE <u>West</u> LINE, SECTION <u>4</u> TOWNSHIP <u>11 S</u> RANGE <u>34 E</u> N.M.P.M.	10. Field and Pool, or Wildcat Inbe Permo Penn.
15. Elevation (Show whether DF, RT, GR, etc.) 4218 Gr.	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging operations to begin approximately 5-31-71 as follows:

1. Spot 25 sack plug across perfs 9921-9929.
2. Fill hole with 9.5# mud.
3. Locate free point, shoot and pull 5 1/2" casing.
4. Spot 100 ft. plug in and out of 5 1/2" casing stub, and at 7673-7773, 5414-5514, 3990-4090.
5. Shoot and pull 8 5/8" casing from approx. 1200 ft.
6. Spot plugs: 100 ft. plug in and out 8 5/8 casing stub; 2685-2785, 1910-2010, 350-450, 10 sacks at surface.
7. Set marker; clear location and level all pits.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>[Signature]</u>	TITLE <u>Proration Clerk</u>	DATE <u>4-30-71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT 1</u>	DATE <u>MAY 3 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		