

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-70

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator: American Exploration Company	8. Farm or Lease Name: Vada Pruitt
3. Address of Operator: 2100 RepublicBank Bldg., Houston, Texas 77002	9. Well No.: 1
4. Location of Well: UNIT LETTER L 2310 FEET FROM THE South LINE AND 660 FEET FROM West THE LINE, SECTION 14 TOWNSHIP 9S RANGE 34E NMPM.	10. Field and Pool, or Wildcat: Vada Pennsylvanian
15. Elevation (Show whether DF, RT, GR, etc.)	12. County: Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

American Exploration Company proposes to plug and abandon the subject well as follows:

1. MIRU PU. POH w/rods and pump. Release anchor. NU BOPS. POH w/tbg. RU wireline unit and RIH. Set CIBP @ 9750' with 35' cement on plug. Determine free point and cut off 4-1/2" casing. Pull free 4-1/2" casing. Cut and pull free 8-5/8" casing. Set 100' cement plugs 50' above and below the following depths: 4-1/2" casing stub @ 9863', 8-5/8" casing stub @ 4033', 380' (13-3/8" casing shoe).
2. Set 50' surface plug up to 4'. Cut off 13-3/8" casing @ 4'. Top off hole with cement and install dry hole marker. Reclaim location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Marty McClanahan TITLE Production Dept. DATE 1/10/89

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JAN 13 1989

CONDITIONS OF APPROVAL, IF ANY: