

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

OIL CONSERVATION DIVISIO.

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501Form C-103
Revised 10-1-

| | |
|--------------------------------|---|
| 5a. Indicate Type of Lease | |
| State <input type="checkbox"/> | Fed <input checked="" type="checkbox"/> |
| 5. State Oil & Gas Lease No. | |

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/> | 7. Unit Agreement Name |
| 2. Name of Operator Amoco Production Company | 8. Form or Lease Name Rives |
| 3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240 | 9. Well No. 1 |
| 4. Location of well UNIT LETTER N 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 9-S RANGE 34-E N.M.P.M. | 10. Field and Pool, or Whdcat Vada Penn |
| 15. Elevation (Show whether DF, RT, GR, etc.) 4279.4' GL | 12. County Lea |

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

| | | | |
|--|--|--|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOBS <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

Move in service unit. Pull rods and pump. Release tubing anchor and pull tubing. Run in hole with CIBP and set at 8725'. Pressure test CIBP to 500 PSI. Cap CIBP with 35' of cement. Run freepoint survey and cut 5½" casing 100' above freepoint. Spot a 50 sack cement plug across the 5½" casing stub. Pull up and spot a 25 sack cement plug across the 8-5/8" casing shoe at 3972'. Run freepoint and cut 8-5/8" casing 100' above freepoint. Pull 8-5/8" casing. Spot a 50 sack cement plug across the 8-5/8" casing stub. Pull up and spot a 50 sack cement plug across the 11-3/4" casing shoe at 315'. Spot a 10 sack surface plug. Weld on cap and erect PXA marker.

THE OPERATOR MUST BE NOTIFIED 24
HOURS BEFORE THE BEGINNING OF
PLUG AND ABANDONMENT FOR THIS C-103
TO BE APPROVED.

0+5-NMOCD,H

1-HOU

1-DMF

1-W. Stafford, HOU

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mark Freeman TITLE Assist. Admin. Analyst DATE 12-17-82APPROVED BY JERRY SEXTON TITLE DISTRICT 1 SUPR. DATE DEC 21 1982

RECEIVED

RECEIVED

RECEIVED

DEC 20 1982

NOV 20 1982