

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division

P.O. Box 1980

Hobbs, NM 88241

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—PRODUCTION PROPOSALS"

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Permian Resources, Inc. DBA Permian Partners, Inc.

3. Address and Telephone No.

P.O. Box 590 Midland, Texas 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

SESW Sec. 22 T09S, R37E

5. Lease Designation and Serial No.

NMNM050475A

6. If Indian, Allottee or Tribe Name

7. If Unit or C.A. Agreement Designation

8. Well Name and No

Federal 22 #1

9. API Well No.

30-025-23680

10. Field and Pool, or Exploratory Area

West Sawyer San Andres

11. County or Parish, State

Lea County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other Plug & Abandon

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Operator will notify BLM of plugging operations and plug and abandon well as follows:

- RIH with 2 3/8" tubing. Set 100' plug above perforations 4997 Tag. Displace with mud.

- Pull stretch on 4 1/2' casing and cut casing - place 100' plug at casing stub. Tag plug

** - Place 100' plug at casing shoe in 8 5/8' at approximately 433' - Tag.

- Place 50' minimum plug at surface, weld on cap, install P&A marker 6' above ground level. Clean Location.

* Spot cement plug from 5031' (POTD) to 4900' minimum. Tag plug.

** If casing cut & pulled from estimated TOC at 4200', spot additional plugs in open hole: 100' cmt. 2930'-2830', & 100' cmt. 2350'-2250'.

If 4 1/2" casing cut between 2900' to 2815' the stub plug will suffice for salt base plug.

I hereby certify that the foregoing is true and correct

Signed

Title

Vice President

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

As modified

Title

APPROVED

PETER W. CHESTER

SEP 28 1998

Date 9-9-98

BUREAU OF LAND MANAGEMENT
ROSKILL LAND RESOURCE AREA

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side