
State of New Mexico nergy, Minerals and Natural Resources Departn

Form	C-103
Revis	ed 1-1-89

DETRICT I P.O. Box 1980, Hobbs, NM 88240 OIL CONSERVA		WELL API NO.
P.O. Box 1980, Hoose, NM 88240 P.O. Bo DISTRICT II Santa Fe, New Me		3002524392
P.O. Drawer DD, Artesia, NM 88210	A100 0750 . 2000	5. Indicate Type of Lesse STATEXX FEE
DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410		6. State Oil & Gas Lease No. L-494
SUNDRY NOTICES AND REPORTS ON	WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DE DIFFERENT RESERVOIR. USE "APPLICATION FO (FORM C-101) FOR SUCH PROPOSALS.	EPEN OR PLUG BACK TO A OR PERMIT"	7. Lease Name or Unit Agreement Name
1. Type of Weil: OIL GAS WELL X WELL OTHER		MIDWEST-STATE
2. Name of Operator		8. Well No.
FOSSIL FUELS INC. 3. Address of Operator		9. Pool name or Wildcat
P.O. BOX 479 DALLAS, TX. 75221		VADA (PENN.)
4. Well Location		
Unit Letter N: 990 Feet From The SOUTH	Line and 165	0 Feet From The WEST Line
Section 2 Township 9-S	Range 33-E	NMPM LEA County
10. Elevation (Show wi	heiher DF, RKB, RT, GR, etc.)	
4347' GL		The Other Date
11. Check Appropriate Box to India NOTICE OF INTENTION TO:		SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS	COMMENCE DRILLING	OPNS. PLUG AND ABANDONMENT
PULL OR ALTER CASING	CASING TEST AND CE	MENT JOB
OTHER:	OTHER:	
12. Describe Proposed or Completed Operations (Clearly state all pertinent deta		
	nils, and give pertinent dates, inche	ling estimated date of starting any proposed
work) SEE RULE 1103.		
wort) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on	top (Top perfs	@ 8653').
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/l0# bri	top (Top perfs ne w/ 25# gel/b	@ 8653').
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs	@ 8653'). bl. g stub. Tag.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/l0# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937'	@ 8653'). bl. g stub. Tag.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00').	@ 8653'). bl. g stub. Tag. - 3837'.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/l0# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8	@ 8653'). bl. g stub. Tag. - 3837'. " csg stub. Tag.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8"	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'-	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug & 13 3/8" 9. Spot 10 sx cmt plug @ surf, we	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8"	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker.
work) SEE RULE 1103. 1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri: 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug & 13 3/8" 9. Spot 10 sx cmt plug @ surf, we	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug & 50' in & 5 8. Spot 75 sx cmt plug & 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker. 5/94.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker. 5/94.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker. 5/94.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2 ge and belief. _ musAgent	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker. 5/94. DATE 5/09/94 (214) 363-7143 TELEPHONE NO.
1. Set CIBP @ 8630' w/35' cmt on 2. TIH w/tbg. Load hole w/10# bri 3. Cut & pull 7" csg (est. @ 6500 4. Spot 30 sx cmt plug 50' in & 5 5. Spot 40 sx cmt plug @ 9 5/8" c 6. Cut & Pull 9 5/8" csg (est. 20 7. Spot 60 sx cmt plug 50' in & 5 8. Spot 75 sx cmt plug @ 13 3/8" 9. Spot 10 sx cmt plug @ surf, we Plugging operations to commence ap	top (Top perfs ne w/ 25# gel/b '). 0' out of 7" cs sg shoe, 3937' 00'). 0' out of 9 5/8 csg shoe, 460'- ld on steel pla proximately 5/2	@ 8653'). bl. g stub. Tag 3837'. " csg stub. Tag 360'. te, install DH marker. 5/94. DATE 5/09/94 (214) 363-7143 TELEPHONE NO.

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C403 TO BE APPROVED



OFFICE