

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator BTA OIL PRODUCERS		8. Farm or Lease Name Brewer, 689-C Ltd.
3. Address of Operator 104 South Pecos Midland, Texas 79701		9. Well No. 2
4. Location of Well UNIT LETTER 'H' 1900 FEET FROM THE North LINE AND 560 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 12-S RANGE 33-E NMPM.		10. Field and Pool, or Wildcat Bagley, North (Penn.)
15. Elevation (Show whether DF, RT, GR, etc.) 4289' GL 4299' DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIATION WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Procedure:

Spot 40 sx plug @ 8500' & Tag Plug.
Cut & pull 5 1/2" csg - T/C 7300'
Set 40 sx plug @ 5 1/2" stub - tag plug
Set 40 sx plug @ 5200' (Glorieta)
Set 50 sx plug @ 3757' (8-5/8" Shoe)- tag plug.
Cut & Pull - 8-5/8" csg - T/C 2010'
If salt exposed, Set 60 sx plug @ 1750' - If salt is not exposed, Perf 8-5/8" csg @1750' & sqz w/60 sx.
Set 75 sx plug @ 8-5/8" stub - tag plug
Set 75 sx plug @ 450' (13-3/8" shoe) - tag plug
Set 10 sx plug @ Surface.
Install Dry Hole Marker

4.5 mud. between
plug
Tag - all stub &
shoe plugs.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L. D. Boyce

TITLE Production Supervisor

DATE 2/15/84

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____

TITLE _____

DATE FEB 17 1984

CONDITIONS OF APPROVAL, IF ANY: