

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
BLM - CARLSBAD

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-15452-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Wildlife Federal

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec3-T9S-R33E

12. COUNTY OR PARISH

Lea

13. STATE

NM

SUNDRY NOTICES AND REPORTS OF WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. WELL TYPE
WELL XX WELL OTHER

SEP 18 11 24 AM '90

2. NAME OF OPERATOR

Hanson Operating Company, inc.

3. ADDRESS OF OPERATOR

P. O. Box 1515, Roswell, New Mexico 88202-1515

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

At surface

1830' FSL & 660' FEL

Unit I

14. PERMIT NO

API #30-025-25042

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4353.6 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR VALVE

CHANGE PLAN

OTHER

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Upon conversation w/Adam Salameh w/ BLM in Carlsbad, HOCI

plans to P&A in the following manner: 1. Set a cement retainer @ 7200'. HOCI is experiencing problems in the 5-1/2" csg @7250' in the manner of collapsing. 2. Sting into retainer and pmp 50sx of Class "H" cement into well bore. 3. Pull out of retainer and cap w/50' of Class "H" cement, and tag. 4. Pull tbg to 2580' and set a 100' Class "C" cement plug at base of salt. 5. Perforate @ 3950' and set a 100' Class "C" cement plug outside and 100' plug inside top of salt and tag plug. 6. Set a 100' Class "C" cement plug 50' outside surface csg & 50' inside csg. 7. RD, clean location, set dry hole marker. All plugs will be set w/9# mud laden fluid w/25# gel per bbl. BLM will be notified 24 hrs in advance in Hobbs @ 393-3612.

18. I hereby certify that the foregoing is true and correct

SIGNED

Lisa J. Jennings

TITLE

Production Analyst

DATE 9/14/90

(This space for Federal or State office use)

APPROVED BY

TITLE

PETROLEUM ENGINEER

DATE

9-20-90

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side