

NO. OF COPIES RECEIVED

DISTRIBUTION

SANTA FE

FILE

U.S.G.S.

LAND OFFICE

OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease

State ☐Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Ike Lovelady, Inc.		8. Farm or Lease Name Sheridan
3. Address of Operator P.O. Drawer 2666; Midland, Texas 79702		9. Well No. 1
4. Location of Well UNIT LETTER <u>E</u> <u>1980'</u> FEET FROM THE <u>north</u> LINE AND <u>660'</u> FEET FROM THE <u>west</u> LINE, SECTION <u>1</u> TOWNSHIP <u>9-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4334.2 RT		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:PERFORM REMEDIAL WORK ☐TEMPORARILY ABANDON ☐PULL OR ALTER CASING ☐PLUG AND ABANDON ☒CHANGE PLANS ☐OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐COMMENCE DRILLING OPNS. ☐CASING TEST AND CEMENT JOBS ☐OTHER ☐ALTERING CASING ☐PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well drilled to total depth of 9657'. Csg. strings set as follows 12-3/4" set @ 404' cement cir. W/425 Sks; 8-5/8" set @ 3876' W/275 Sks; 5-1/2" set @ 9657' W/475 Sks; perforated 5-1/2" Csg. 9582' to 9592', Csg. collapsed on tbg. & rods @ 8089'. Washed over & cut Tbg. @ 8595'. Unable to get back inside 5-1/2" csg. @ 8089' after we pulled out of hole W/cut off tubing. We purpose to set CIBP @ 8000' W/35' cement on top cut off 5-1/2" Csg. @ Approx. 5500'. Set 100' plug @ stub- 50' in & 50' out. Set 100' plug across 8-5/8" shoe @ 3876'. Set 100' plug @ stub of 8-5/8" Csg.-50' in & 50' out. Set 100' plug across shoe of surface csg. @ 404', set 10 sks @ surface @/dry hole marker. Clean Location & get inspected.

(NOTE: WILL CALL NEW MEXICO OIL CONSERVATION COMMISSION BEFORE STARTING PLUGGING PROCEDURE)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

TITLE Manager of Drlg. & Production DATE 7/10/79

Orig. Signed by

Jerry Sexton

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY Dist 1. Supv.

JUL 18 1979