

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

240 NM - 56262

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Price Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 5, T-9-S, R-34-E

12. COUNTY OR PARISH

Lea

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
TXO Production Corp.

3. ADDRESS OF OPERATOR
900 Wilco Building

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FSL & 660' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4294.2' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Load hole w/ 9# brine wtr. Inst BOP.
2. Set CIBP w/ 35' cmt @ 9585'. Tag.
3. Set 100' cmt plug from 8995-8895'. (15 sx).
4. Set 100' cmt plug from 7848-7948'. (15 sx).
5. Set 100' cmt plug from 7638-7738'. (15 sa).
6. Free pt., cut and pull 5 1/2" csg.
7. Set 100' cmt plug 50' in and out of Stub. (30 sx). Tag.
8. Set 100' cmt plug from 5284-5384'. (35 sx).
9. Set 100' cmt plug from 3950-4050'. (50 sx). [This is 50' in and out of 8 5/8" csg].
10. Set 100' cmt plug from 2619-2719'. (50 sx).
11. Set 100' cmt plug from 450-550'. (50 sx).
12. Set 10 sx at surface. plug = 50'
13. Set marker. Fill pits. Clean location.

RECEIVED
SEP 21 11 01 AM '83
RUSTENBURG

18. I hereby certify that the foregoing is true and correct

SIGNED

Deen Ward

TITLE

Production Engineer

DATE

9-16-83

(This space for Federal or State use only)

(Orig. Sgd.)

PETER W. CHESTER

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

OCT 13 1983

*See Instructions on Reverse Side

RECEIVED
OCT 14 1983
G.D.
HOBBS OFFICE