

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Ronadero Company, Inc.	8. Firm or Lease Name Ronalto
3. Address of Operator Box 430 Roswell, N.M. 88240	9. Well No. 2
4. Location of Well UNIT LETTER <u>D</u> <u>320</u> FEET FROM THE <u>A</u> LINE AND <u>3310</u> FEET FROM THE <u>6</u> LINE, SECTION <u>14</u> TOWNSHIP <u>12S</u> RANGE <u>32E</u> N.M.P.M.	10. Field and Pool, or Wildcat East Caprock Penn
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in and rig up. Install BOP and unset packer. Circulate oil out of backside.

Circulate with mud laden fluid. Pull out of hole with tubing and packer. (Lay down extra tubing.) Set Cast Iron Bridge Plug with wireline at 10,345' and cap with cement.

Nipple up to 5½" casing. Cut and pull to plus or minus 6140'. Go in hole with tubing. Spot stub plug with 30 sacks and tag. Spot plug at top of Glorietta with 30 sacks plus or minus 5800'. Spot plug at top of San Andres with 30 sacks plus or minus 4200'. Spot plug at top of Salt with 30 sacks plus or minus 1500'.

10 sacks at surface plug and install marker.

Rig down and clean location.

THIS IS A PRELIMINARY REPORT NO. 24
SUBMITTED TO THE COMMISSION OF
PETROLEUM AND MINERALS FOR THE CHOS
TO BE REVIEWED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>Jerry Sexton</u>	TITLE <u>E. V. Pres</u>	DATE <u>1/3/86</u>
APPROVED BY <u>ORIGINAL SIGNED BY JERRY SEXTON</u>	TITLE <u>DISTRICT 1 SUPERVISOR</u>	DATE <u>JAN 9 1986</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED
JAN 8 - 1986
O.C.D.
HOBBS OFFICE