

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-29500
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG-4770

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

Internorth ADG State

8. Well No.

1

9. Pool name or Wildcat

Und. Lea Group 6

1. Type of Well:  
Oil ☒ WELL GAS ☐ WELL OTHER ☐

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South Fourth Street - Artesia, NM 88210

4. Well Location

Unit Letter A : 660 Feet From The North Line and 660 Feet From The East Line  
Section 25 Township 11S Range 34E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4142.3' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Set CIBP at 10000' and cap with 35' of cement.
2. Set CIBP at 9075' and cap with 35' of cement.
3. Cut and pull 5-1/2" casing. Temperature Survey indicated top of cement to be at 7150'.
4. Set a 100' cement plug across 5-1/2" casing stub.
5. Set a 100' cement plug across the Glorieta top at 5596'.
6. Set a 100' cement plug across the 8-5/8" casing shoe at 4261'.
7. Set a 100' cement plug across the 13-3/8" casing shoe at 407'.
8. Set a 10 sack surface plug.
9. Install regulation abandonment marker.

NOTIFY OCD - HOBBS (505-393-6161) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Rusty Klein*

TITLE Production Clerk

DATE 11-14-94

505-748-1471  
TELEPHONE NO.

TYPE OR PRINT NAME

Rusty Klein

(This space for State Use)

APPROVED BY

TITLE

DATE

NOV 17 1994